



▪ Empreintes collection - Ligne series - Gun metal - 1 button

	INSPIRATION SOURCE BOOK	192
E.1	FORMATS AND FINISHES	194
E.2	COVER PLATES WITH BUTTONS	200
	Mechanisms	200
	Plan Series	202
	Volume Series	212
	Angle Series	222
	Point Series	232
	Line Series	242
E.3	HOME AUTOMATION	250
	Semi-integrated home automation	250

E.1
E.2
E.3

INSPIRATIONAL SOURCE BOOK

The **Empreintes** collection was designed by interior designers and architects **Astrid Dieterlen and Bruno Borrione**. The design explores **dimension** and **texture**, drawing on the fundamental principles of architecture. From a distance, the object appears understated. Up close, the material reveals the precision of its craftsmanship. **Empreintes** is a collection with a **radical design**, crafted from **solid brass** and available in **five series: Plan, Volume, Angle, Point, and Ligne**.

Five series, five architectural principles engraved in brass.

A collection that reinterprets classic design, with precision as its **guiding principle**.

The switch is no longer a minor detail, but a true **design object**, shaped by refined craftsmanship.



▪ Empreintes collection – Old bronze – 1 button



▪ Empreintes collection – Volume series – Gun metal – 1 button + 2P+E socket




E.1
E.2
E.3

- Empreintes collection – Angle series – Old bronze – 1 switch + 1 schuko socket

EMPREINTES COLLECTION ■ FORMATS AND FINISHES

NEW


PLAN COVER PLATE - SATIN NICKEL - 478



SATIN NICKEL TWO-WAY BUTTON
088-011G478

NEW


PLAN COVER PLATE - SATIN BRASS - 479



SATIN BRASS TWO-WAY BUTTON
088-011G479

NEW


LIGNE COVER PLATE - OLD BRONZE - 477



OLD BRONZE PUSH BUTTON
088-021G477

NEW

PLAN COVER PLATE - SATIN BRASS - 479



2 SATIN BRASS TWO-WAY BUTTONS
088-012G479

VOLUME COVER PLATE - OLD BRONZE - 477

NEW



OLD BRONZE PUSH BUTTON
088-021G477

POINT COVER PLATE - GUN METAL - 474


NEW



GUN METAL TWO-WAY BUTTON
088-011G474


ANGLE COVER PLATE - SATIN NICKEL - 478

NEW



SATIN NICKEL PUSH BUTTON
088-021G478

- E.1
- E.2
- E.3




Create your
compositions on our
online configurator
www.my.modelec.com
Details p. 400

DIMENSIONS OF COVER PLATES

Single cover plate


E0 - E2 - E4 : 80x80x5mm
E1 - E5 : 80x80x6mm



S

Double horizontal cover plate


E0 - E2 - E4 : 151x80x5mm
E1 - E5 : 151x80x6mm



DH

Triple horizontal cover plate


E0 - E2 - E4 : 222x80x5mm
E1 - E5 : 222x80x6mm



TH

Double vertical cover plate

E0 - E2 - E4 : 80x151x5mm
E1 : 80x151x6mm




DV

The E5 - LIGNE series is not
available in a double vertical
format

Triple vertical cover plate

E0 - E2 - E4 : 80x222x5mm
E1 : 80x222x6mm



TV

The E5 - LIGNE series is not
available in a triple vertical for-
mat

Cover plates in the Plan, Angle and Volume series can be engraved (see p. 373).

FIXING - MOUNTING

Recommendation:

For added convenience, we have designed our switches to fit standard flush-mount boxes.
For single, double, triple cover plates: diameter 67-68mm, depth 50 mm.

Mounting: flush-mount

Montage Cover plate: magnetised

Connection: our cover plates are mounted without earth connection

A complete electrical switch needs a cover plate reference to be linked to the reference for the corresponding mechanism(s).

Standard patterns, please ask us if you have other requirements.

FUNCTIONS CODES

220V	220V							
D1	D2E	R1	K1	M1	M2	M8	U1	U3
Two-way Push button	Double two-way Double push button	Socket 2P+E	Socket 2P+E	RJ45 HP HDMI...	Double RJ45 Double HP ...	TV + RJ45	USB charger A+A A+C C+C	Power delivery USB C
V1	T1	SC	C1	C3	R2	R3	R4	O1
Dimmer	Thermostat Not available for E5 Series - LINE	Cable outlet	TV	TV FM SAT	Motion detector Badge reader ...	Italian Bipasso socket 2P+E	Swiss socket 2P+E	Obturateur


The Empreintes collection is also available in semi-integrated home automation option (see p. 250).

E.1

E.2

E.3

The Empreintes collection is also available with our low-voltage square buttons, which are compatible with home automation systems and can be supplied either pre-wired or without a Theben module.




The buttons are available with or without an LED (5V).

- Dimensions of the flat square button: 12.5 x 12.5 mm



The operating voltage of the LED is 5V, a common value for a home automation input module.
For 8V supplies, the 076KIT200 protection kit is mandatory.
For higher voltages, please specify it when ordering.




There are plenty of options available: up to 4 controls on a single mechanism (i.e. 15 functions) and the option to add indicator lights (up to 4 controls with LED indicators).

Cover plates and buttons can be engraved.

EMPREINTES COLLECTION ■ FORMATS AND FINISHES

■ EMPREINTES SERIES

PLAN - E0



VOLUME - E1



ANGLE - E2



POINT - E4




LIGNE - E5




COVER PLATE FINISHES

Solid brass plates, available in six finishes.



Matt White
471



Matt Black
472



Gun Metal
474



Old Bronze
477



Satin Nickel
478



Satin Brass
479

E.1
E.2
E.3

FLAT BUTTONS FINISHES

Solid brass square flat buttons, available in six finishes to match the plates.



Matt White



Matt Black



Gun Metal



Old Bronze



Satin Nickel



Satin Brass

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

SOCKETS AND MEDIA MECHANISMS

These mechanisms can be used for single, double and triple cover plates.

Sockets and media mechanisms			Mechanisms references	RETAIL PRICE EX TAX				Mechanisms references	RETAIL PRICE EX TAX
-320G		Mechanism socket 2P+E	087-320G	13,80 €	-470G		Mechanism loud speaker white	087-470G	18,10 €
-620G		Mechanism schuko socket	087-620G	13,60 €	-471G		Mechanism loud speaker black	087-471G	18,10 €
-270G		Mechanism rotary dimmer	087-270G	88,40 €	-480G		Mechanism double loud speaker white	087-480G	34,60 €
-291G		Mechanism thermostat	087-291G	230,70 €	-481G		Mechanism double loud speaker black	087-481G	34,60 €
-510G		Mechanism double USB charger A+A	087-510G	76,20 €	-641G		Mechanism motion detector white (2 wires)	087-641G	190,50 €
-511G		Mechanism double USB charger A+C	087-511G	88,60 €	-651G		Mechanism motion detector black (2 wires)	087-651G	190,50 €
-512G		Mechanism double USB charger C+C	087-512G	86,30 €	-640G		Mechanism motion detector white (3 wires)	087-640G	190,50 €
-540G		Mechanism power delivery USB C	087-540G	127,50 €	-650G		Mechanism motion detector black (3 wires)	087-650G	190,50 €
-935G		Mechanism TV + RJ45 cat 6 white	087-935G	51,80 €	-520G		Mechanism badge reader white	087-520G	146,10 €
-940G		Mechanism TV + RJ45 cat 6A screened white	087-940G	58,20 €	-530G		Mechanism badge reader black	087-530G	146,10 €
-945G		Mechanism TV + RJ45 cat 6A screened black	087-945G	64,30 €	-780G		Single mechanism 1 swiss socket 2P+E white	087-780G	17,00 €
-360G		Mechanism TV	087-360G	33,40 €	-781G		Single mechanism 1 swiss socket 2P+E black	087-781G	17,00 €
-370G		Mechanism TV/FM/SAT simple entry	087-370G	65,00 €	-785G		Single mechanism 1 double swiss socket 2P+E white	087-785G	33,80 €
-380G		Mechanism TV/FM/SAT double entry	087-380G	65,00 €	-785G		Single mechanism 1 double swiss socket 2P+E black	087-785G	33,80 €
-190G		Mechanism cable outlet	087-190G	12,60 €	-790G		Single mechanism 1 italian bipasso socket 2P+E white	087-790G	17,00 €
-161G		Bare mechanisms for shutter	087-161G	4,80 €	-791G		Single mechanism 1 italian bipasso socket 2P+E black	087-791G	17,00 €
-390G		Mechanism RJ45 Cat 6 (3M) white	087-390G	22,80 €	-795G		Single mechanism 1 double italian bipasso socket 2P+E white	087-795G	33,80 €
-400G		Mechanism double RJ45 Cat 6 white	087-400G	43,90 €	-796G		Single mechanism 1 double italian bipasso socket 2P+E black	087-796G	33,80 €
-490G		Mechanism RJ45 Cat 6 + HDMI white	087-490G	89,60 €	-625G		Single mechanism italian schuko socket 2P+E white	087-625G	23,20 €
-491G		Mechanism RJ45 Cat 6A SCREENED black + HDMI black	087-491G	101,20 €	-626G		Single mechanism italian schuko socket 2P+E black	087-626G	23,20 €
-410G		Mechanism RJ45 Cat 6A SCREENED white	087-410G	34,60 €	-740G		Single mechanism 1 Euro-US socket 2P+E white	087-740G	23,20 €
-411G		Mechanism RJ45 Cat 6A SCREENED black	087-411G	34,60 €	-741G		Single mechanism 1 Euro-US socket 2P+E black	087-741G	23,20 €
-420G		Mechanism double RJ45 Cat 6A SCREENED white	087-420G	67,60 €	-760G		Single mechanism 1 UK socket 2P+E white	087-760G	23,20 €
-421G		Mécanisme double RJ45 Cat 6A SCREENED black	087-421G	67,60 €	-761G		Single mechanism 1 UK socket 2P+E black	087-761G	23,20 €
-430G		Mechanism HDMI black	087-430G	51,90 €	-720G		Single mechanism 1 multistandard socket 2P+E white	087-720G	24,00 €
-431G		Mechanism HDMI white	087-431G	51,90 €	-730G		Single mechanism 1 multistandard socket 2P+E black	087-730G	24,00 €
-440G		Mechanism double HDMI black	087-440G	102,40 €					
-441G		Mechanism double HDMI white	087-441G	102,40 €					

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

AUTOMATIC CONNECTION MECHANISMS

These mechanisms can be used for single, double and triple cover plates.

NEW

Square toggle two-way and push-button switches - 230V

				MATT WHITE Button 471	MATT BLACK Button 472	RETAIL PRICE EX TAX	GUN METAL Button 474	OLD BRONZE Button 477	RETAIL PRICE EX TAX	SATIN NICKEL Button 478	SATIN BRASS Button 479	RETAIL PRICE EX TAX
Two-way	-011G	□	Mechanism 1 two-way push button - 230V	088-011G471	088-011G472	33,50 €	088-011G474	088-011G477	33,50 €	088-011G478	088-011G479	33,50 €
	-012G	□□	Mechanism 2 two-way push buttons - 230V	088-012G471	088-012G472	57,40 €	088-012G474	088-012G477	57,40 €	088-012G478	088-012G479	57,40 €
Push-toggle	-021G	□	Mechanism 1 push button - 230V	088-021G471	088-021G472	32,40 €	088-021G474	088-021G477	32,40 €	088-021G478	088-021G479	32,40 €
	-022G	□□	Mechanism 2 push buttons - 230V	088-022G471	088-022G472	55,50 €	088-022G474	088-022G477	55,50 €	088-022G478	088-022G479	55,50 €
Mixed	-015G	□□	Mechanism 1 two-way + 1 push buttons - 230V	088-015G471	088-015G472	56,30 €	088-015G474	088-015G477	56,30 €	088-015G478	088-015G479	56,30 €

E.1

E.2



E.3

A LONG-AWAITED INNOVATION: THE 230V TWO-WAY PUSH BUTTON

The square button from **Empreintes** is available in **two versions**: In **two-way mode**, it can be installed on standard lighting circuits with **one or two switch points**, allowing lighting to be controlled from two separate locations.

In **push-button mode**, it transmits a **230V pulse** via a **remote switch, remote dimmer, relay, or wired automation system**, allowing for the management of multiple control points **without modifying the existing wiring**.

This switch can thus adapt to any installation configuration.



EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

PLAN



- Empreintes collection – Plan series – Gun metal – 1 Button

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

PLAN

SINGLE COVER PLATES - PLAN - E0

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Single cover plates - Plan - E0

Single cover plate dimensions:
80x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
131-		Cover plate 1 button slot for 230V mechanism	131-471M-E0	131-472M-E0	131-474M-E0	131-477M-E0	131-478M-E0	131-479M-E0
132-		Cover plate 2 buttons slots for 230V mechanism	132-471M-E0	132-472M-E0	132-474M-E0	132-477M-E0	132-478M-E0	132-479M-E0
RETAIL PRICE EX TAX			83,00 €	83,00 €	85,70 €	85,70 €	83,80 €	83,80 €
190-		Cover plate socket 2P+E	190-471M-E0	190-472M-E0	190-474M-E0	190-477M-E0	190-478M-E0	190-479M-E0
190-K		Cover plate schuko socket	190-471M-E0K	190-472M-E0K	190-474M-E0K	190-477M-E0K	190-478M-E0K	190-479M-E0K
RETAIL PRICE EX TAX			86,40 €	86,40 €	90,50 €	90,50 €	87,50 €	87,60 €
189-		Cover plate double USB charger slot	189-471M-E0	189-472M-E0	189-474M-E0	189-477M-E0	189-478M-E0	189-479M-E0
200-		Cover plate power delivery USB C slot	200-471M-E0	200-472M-E0	200-474M-E0	200-477M-E0	200-478M-E0	200-479M-E0
192-		Cover plate 1 MEDIA slot	192-471M-E0	192-472M-E0	192-474M-E0	192-477M-E0	192-478M-E0	192-479M-E0
193-		Cover plate 2 MEDIA slots	193-471M-E0	193-472M-E0	193-474M-E0	193-477M-E0	193-478M-E0	193-479M-E0
210-		Cover plate 1 TV slot + 1 RJ45 slot	210-471M-E0	210-472M-E0	210-474M-E0	210-477M-E0	210-478M-E0	210-479M-E0
194-		Cover plate 1 TV slot	194-471M-E0	194-472M-E0	194-474M-E0	194-477M-E0	194-478M-E0	194-479M-E0
196-		Cover plate TV/FM/SAT slots	196-471M-E0	196-472M-E0	196-474M-E0	196-477M-E0	196-478M-E0	196-479M-E0
198-		Cover plate for shutter	198-471M-E0	198-472M-E0	198-474M-E0	198-477M-E0	198-478M-E0	198-479M-E0
RETAIL PRICE EX TAX			94,00 €	94,00 €	96,00 €	96,00 €	97,80 €	97,80 €
187-		Cover plate thermostat + button	187-471M-E0	187-472M-E0	187-474M-E0	187-477M-E0	187-478M-E0	187-479M-E0
RETAIL PRICE EX TAX			139,00 €	139,00 €	143,20 €	143,20 €	142,90 €	142,90 €
191-		Cover plate rotary dimmer slot	191-471M-E0	191-472M-E0	191-474M-E0	191-477M-E0	191-478M-E0	191-479M-E0
RETAIL PRICE EX TAX			118,40 €	118,40 €	123,50 €	123,50 €	121,00 €	121,00 €
190-CL		Cover plate 2P+E socket with flap	190-471M-E0CL	190-472M-E0CL	190-474M-E0CL	190-477M-E0CL	190-478M-E0CL	190-479M-E0CL
190-CLK		Cover plate Schuko socket with flap	190-471M-E0CLK	190-472M-E0CLK	190-474M-E0CLK	190-477M-E0CLK	190-478M-E0CLK	190-479M-E0CLK
RETAIL PRICE EX TAX			172,80 €	172,80 €	181,00 €	181,00 €	175,20 €	175,20 €
190-S		Cover plate 1 swiss socket	190-471M-E0S	190-472M-E0S	190-474M-E0S	190-474M-E0S	190-478M-E0S	190-479M-E0S
190-DS		Cover plate 1 double swiss socket	190-471M-E0DS	190-472M-E0DS	190-474M-E0DS	190-474M-E0DS	190-478M-E0DS	190-479M-E0DS
190-I		Cover plate 1 bipasso socket	190-471M-E0I	190-472M-E0I	190-474M-E0I	190-474M-E0I	190-478M-E0I	190-479M-E0I
199-		Cover plate for 45x45 module	199-471M-E0	199-472M-E0	199-474M-E0	199-477M-E0	199-478M-E0	199-479M-E0
RETAIL PRICE EX TAX			86,40 €	86,40 €	90,50 €	90,50 €	87,60 €	87,60 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

PLAN

DOUBLE HORIZONTAL COVER PLATES - PLAN - EO

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Plan - EO

Double cover plate dimensions:
151x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
	Recommended button color		Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
172-		Cover plate 2 buttons slots	172-471M-E0	172-472M-E0	172-474M-E0	172-477M-E0	172-478M-E0	172-479M-E0
177-		Cover plate 1 button + 2 buttons slots	177-471M-E0	177-472M-E0	177-474M-E0	177-477M-E0	177-478M-E0	177-479M-E0
SYM 177-		Cover plate 2 buttons + 1 button slots	SYM177-471M-E0	SYM177-472M-E0	SYM177-474M-E0	SYM177-477M-E0	SYM177-478M-E0	SYM177-479M-E0
174-		Cover plate 4 buttons slots	174-471M-E0	174-472M-E0	174-474M-E0	174-477M-E0	174-478M-E0	174-479M-E0
229-		Cover plate double USB charger slot + 2 buttons slots	229-471M-E0	229-472M-E0	229-474M-E0	229-477M-E0	229-478M-E0	229-479M-E0
236-		Cover plate 2 buttons slots + double USB charger slot	236-471M-E0	236-472M-E0	236-474M-E0	236-477M-E0	236-478M-E0	236-479M-E0
255-		Cover plate 1 TV slot + 1 double USB charger slot	255-471M-E0	255-472M-E0	255-474M-E0	255-477M-E0	255-478M-E0	255-479M-E0
256-		Cover plate 1 double USB charger slot + 1 MEDIA slot	256-471M-E0	256-472M-E0	256-474M-E0	256-477M-E0	256-478M-E0	256-479M-E0
257-		Cover plate 1 double USB charger slot + 1 TV	257-471M-E0	257-472M-E0	257-474M-E0	257-477M-E0	257-478M-E0	257-479M-E0
258-		Cover plate double USB charger slot + TV/FM/SAT slots	258-471M-E0	258-472M-E0	258-474M-E0	258-477M-E0	258-478M-E0	258-479M-E0
259-		Cover plate socket 2P+E + 1 double USB charger slot	259-471M-E0	259-472M-E0	259-474M-E0	259-477M-E0	259-478M-E0	259-479M-E0
260-		Cover plate double socket 2P+E	260-471M-E0	260-472M-E0	260-474M-E0	260-477M-E0	260-478M-E0	260-479M-E0
261-		Cover plate 1 button slot + 1 socket 2P+E	261-471M-E0	261-472M-E0	261-474M-E0	261-477M-E0	261-478M-E0	261-479M-E0
262-		Cover plate 2 buttons slots + 1 socket 2P+E	262-471M-E0	262-472M-E0	262-474M-E0	262-477M-E0	262-478M-E0	262-479M-E0
263-		Cover plate socket 2P+E + 1 MEDIA slot	263-471M-E0	263-472M-E0	263-474M-E0	263-477M-E0	263-478M-E0	263-479M-E0
264-		Cover plate 1 socket 2P+E + 2 MEDIA slots	264-471M-E0	264-472M-E0	264-474M-E0	264-477M-E0	264-478M-E0	264-479M-E0
265-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	265-471M-E0	265-472M-E0	265-474M-E0	265-477M-E0	265-478M-E0	265-479M-E0
266-		Cover plate 1 MEDIA slot + 1 MEDIA slot	266-471M-E0	266-472M-E0	266-474M-E0	266-477M-E0	266-478M-E0	266-479M-E0
267-		Cover plate 1 MEDIA slot + 2 MEDIA slots	267-471M-E0	267-472M-E0	267-474M-E0	267-477M-E0	267-478M-E0	267-479M-E0
268-		Cover plate 2 MEDIA slots + 2 MEDIA slots	268-471M-E0	268-472M-E0	268-474M-E0	268-477M-E0	268-478M-E0	268-479M-E0
269-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	269-471M-E0	269-472M-E0	269-474M-E0	269-477M-E0	269-478M-E0	269-479M-E0
270-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	270-471M-E0	270-472M-E0	270-474M-E0	270-477M-E0	270-478M-E0	270-479M-E0
271-		Cover plate 1 MEDIA slot + 1 TV slot	271-471M-E0	271-472M-E0	271-474M-E0	271-477M-E0	271-478M-E0	271-479M-E0
235-		Cover plate 1 MEDIA slot + 1 cable outlet slot	235-471M-E0	235-472M-E0	235-474M-E0	235-477M-E0	235-478M-E0	235-479M-E0
272-		Cover plate 1 socket 2P+E + 1 cable outlet slot	272-471M-E0	272-472M-E0	272-474M-E0	272-477M-E0	272-478M-E0	272-479M-E0
SYM272-		Cover plate 1 cable outlet slot + 1 socket 2P+E	SYM272-471M-E0	SYM272-472M-E0	SYM272-474M-E0	SYM272-477M-E0	SYM272-478M-E0	SYM272-479M-E0
RETAIL PRICE EX TAX			148,00 €	148,00 €	167,10 €	167,10 €	166,10 €	166,10 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

PLAN

DOUBLE HORIZONTAL COVER PLATES - PLAN - EO

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Plan - EO


Double cover plate dimensions:
151x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
273-		Cover plate 1 TV slot + 1 MEDIA slot	273-471M-E0	273-472M-E0	273-474M-E0	273-477M-E0	273-478M-E0	273-479M-E0
274-		Cover plate TV/FM/SAT slot + 1 MEDIA slot	274-471M-E0	274-472M-E0	274-474M-E0	274-477M-E0	274-478M-E0	274-479M-E0
275-		Cover plate 1 button slot + double USB charger slot	275-471M-E0	275-472M-E0	275-474M-E0	275-477M-E0	275-478M-E0	275-479M-E0
276-		Cover plate 1 MEDIA slot + 1 socket 2P+E	276-471M-E0	276-472M-E0	276-474M-E0	276-477M-E0	276-478M-E0	276-479M-E0
279-		Cover plate 1 socket 2P+E+ 1 TV slot	279-471M-E0	279-472M-E0	279-474M-E0	279-477M-E0	279-478M-E0	279-479M-E0
298-		Cover plate 1 MEDIA slot + 1 double USB charger slot	298-471M-E0	298-472M-E0	298-474M-E0	298-477M-E0	298-478M-E0	298-479M-E0
295-		Cover plate 1 double USB charger slot + 1 socket 2P+E	295-471M-E0	295-472M-E0	295-474M-E0	295-477M-E0	295-478M-E0	295-479M-E0
RETAIL PRICE EX TAX			148,00 €	148,00 €	167,10 €	167,10 €	166,10 €	166,10 €
260-CL		Cover plate double socket 2P+E with flap	260-471M-E0CL	260-472M-E0CL	260-474M-E0CL	260-477M-E0CL	260-478M-E0CL	260-479M-E0CL
260-CLK		Cover plate double schuko socket 2P+E with flap	260-471M-E0CLK	260-472M-E0CLK	260-474M-E0CLK	260-477M-E0CLK	260-478M-E0CLK	260-479M-E0CLK
RETAIL PRICE EX TAX			342,00 €	342,00 €	354,20 €	354,20 €	332,00 €	332,00 €

E.1

E.2

E.3



EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

PLAN

DOUBLE VERTICAL COVER PLATES - PLAN - E0

A complete switch consists of a cover plate and single mechanisms for the functions required.

Double vertical cover plates - Plan - E0

Double cover plate dimensions:
80x151x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
152-		Cover plate 2 buttons slots	152-471M-E0	152-472M-E0	152-474M-E0	152-477M-E0	152-478M-E0	152-479M-E0
155-		Cover plate 1 button + 2 buttons slots	155-471M-E0	155-472M-E0	155-474M-E0	155-477M-E0	155-478M-E0	155-479M-E0
SYM 155-		Cover plate 2 buttons + 1 button slots	SYM155-471M-E0	SYM155-472M-E0	SYM155-474M-E0	SYM155-477M-E0	SYM155-478M-E0	SYM155-479M-E0
154-		Cover plate 4 buttons slots	154-471M-E0	154-472M-E0	154-474M-E0	154-477M-E0	154-478M-E0	154-479M-E0
280-		Cover plate double socket 2P+E	280-471M-E0	280-472M-E0	280-474M-E0	280-477M-E0	280-478M-E0	280-479M-E0
281-		Cover plate 1 button slot + 1 socket 2P+E	281-471M-E0	281-472M-E0	281-474M-E0	281-477M-E0	281-478M-E0	281-479M-E0
282-		Cover plate 2 buttons slots + 1 socket 2P+E	282-471M-E0	282-472M-E0	282-474M-E0	282-477M-E0	282-478M-E0	282-479M-E0
293-		Cover plate 1 button slot + double USB charger slot	293-471M-E0	293-472M-E0	293-474M-E0	293-477M-E0	293-478M-E0	293-479M-E0
SYM 293-		Cover plate double USB charger slot + 1 button slot	SYM293-471M-E0	SYM293-472M-E0	SYM293-474M-E0	SYM293-477M-E0	SYM293-478M-E0	SYM293-479M-E0
283-		Cover plate socket 2P+E + 1 MEDIA slot	283-471M-E0	283-472M-E0	283-474M-E0	283-477M-E0	283-478M-E0	283-479M-E0
284-		Cover plate 1 socket 2P+E + 2 MEDIA slots	284-471M-E0	284-472M-E0	284-474M-E0	284-477M-E0	284-478M-E0	284-479M-E0
285-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	285-471M-E0	285-472M-E0	285-474M-E0	285-477M-E0	285-478M-E0	285-479M-E0
286-		Cover plate 1 MEDIA slot + 1 MEDIA slot	286-471M-E0	286-472M-E0	286-474M-E0	286-477M-E0	286-478M-E0	286-479M-E0
287-		Cover plate 1 MEDIA slot + 2 MEDIA slots	287-471M-E0	287-472M-E0	287-474M-E0	287-477M-E0	287-478M-E0	287-479M-E0
288-		Cover plate 2 MEDIA slots + 2 MEDIA slots	288-471M-E0	288-472M-E0	288-474M-E0	288-477M-E0	288-478M-E0	288-479M-E0
289-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	289-471M-E0	289-472M-E0	289-474M-E0	289-477M-E0	289-478M-E0	289-479M-E0
290-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	290-471M-E0	290-472M-E0	290-474M-E0	290-477M-E0	290-478M-E0	290-479M-E0
292-		Cover plate 2 buttons slots + 1 MEDIA slot	292-471M-E0	292-472M-E0	292-474M-E0	292-477M-E0	292-478M-E0	292-479M-E0
RETAIL PRICE EX TAX			148,00 €	148,00 €	167,10 €	167,10 €	166,10 €	166,10 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

PLAN

TRIPLE HORIZONTAL COVER PLATES - PLAN - EO

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple horizontal cover plates - Plan - EO

Triple cover plate dimensions:
222x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
303-		Cover plate 3 buttons slots	303-471M-E0	303-472M-E0	303-474M-E0	303-477M-E0	303-478M-E0	303-479M-E0
304-		Cover plate 1 button + 1 button + 2 buttons slots	304-471M-E0	304-472M-E0	304-474M-E0	304-477M-E0	304-478M-E0	304-479M-E0
305-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	305-471M-E0	305-472M-E0	305-474M-E0	305-477M-E0	305-478M-E0	305-479M-E0
306-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	306-471M-E0	306-472M-E0	306-474M-E0	306-477M-E0	306-478M-E0	306-479M-E0
311-		Cover plate 1 button slot + 2 sockets 2P+E	311-471M-E0	311-472M-E0	311-474M-E0	311-477M-E0	311-478M-E0	311-479M-E0
SYM 311-		Cover plate 2 sockets 2P+E + 1 button slot	SYM311-471M-E0	SYM311-472M-E0	SYM311-474M-E0	SYM311-477M-E0	SYM311-478M-E0	SYM311-479M-E0
312-		Cover plate 2 buttons slots + 2 sockets 2P+E	312-471M-E0	312-472M-E0	312-474M-E0	312-477M-E0	312-478M-E0	312-479M-E0
316-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	316-471M-E0	316-472M-E0	316-474M-E0	316-477M-E0	316-478M-E0	316-479M-E0
341-		Cover plate 2 buttons slots + 1 socket 2P+E + 1 double USB charger slot	341-471M-E0	341-472M-E0	341-474M-E0	341-477M-E0	341-478M-E0	341-479M-E0
342-		Cover plate 1 socket 2P+E + 2 buttons slots + 1 button slot	342-471M-E0	342-472M-E0	342-474M-E0	342-477M-E0	342-478M-E0	342-479M-E0
343-		Cover plate 1 double USB charger slot + 1 socket 2P+E + 1 button slot	343-471M-E0	343-472M-E0	343-474M-E0	343-477M-E0	343-478M-E0	343-479M-E0
345-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	345-471M-E0	345-472M-E0	345-474M-E0	345-477M-E0	345-478M-E0	345-479M-E0
346-		Cover plate 1 button slot + 1 socket 2P+E + 1 double USB charger slot	346-471M-E0	346-472M-E0	346-474M-E0	346-477M-E0	346-478M-E0	346-479M-E0
308-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 button slot	308-471M-E0	308-472M-E0	308-474M-E0	308-477M-E0	308-478M-E0	308-479M-E0
309-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	309-471M-E0	309-472M-E0	309-474M-E0	309-477M-E0	309-478M-E0	309-479M-E0
310-		Cover plate 3 sockets 2P+E	310-471M-E0	310-472M-E0	310-474M-E0	310-477M-E0	310-478M-E0	310-479M-E0
313-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	313-471M-E0	313-472M-E0	313-474M-E0	313-477M-E0	313-478M-E0	313-479M-E0
337-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	337-471M-E0	337-472M-E0	337-474M-E0	337-477M-E0	337-478M-E0	337-479M-E0
314-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	314-471M-E0	314-472M-E0	314-474M-E0	314-477M-E0	314-478M-E0	314-479M-E0
315-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	315-471M-E0	315-472M-E0	315-474M-E0	315-477M-E0	315-478M-E0	315-479M-E0
RETAIL PRICE EX TAX			209,40 €	209,40 €	261,10 €	261,10 €	249,30 €	249,30 €

E.1
E.2
E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

PLAN

TRIPLE HORIZONTAL COVER PLATES - PLAN - EO

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Triple horizontal cover plates - Plan - EO

Triple cover plate dimensions:
222x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
	Recommended button color		471	472	474	477	478	479
			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
344-		Cover plate 2 sockets 2P+E + 1 cable outlet slot	344-471M-E0	344-472M-E0	344-474M-E0	344-477M-E0	344-478M-E0	344-479M-E0
319-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 TV slot	319-471M-E0	319-472M-E0	319-474M-E0	319-477M-E0	319-478M-E0	319-479M-E0
330-		Cover plate 2 MEDIA slots + 1 double USB charger slot	330-471M-E0	330-472M-E0	330-474M-E0	330-477M-E0	330-478M-E0	330-479M-E0
331-		Cover plate 1 double charger USB slot + 2 MEDIA slots	331-471M-E0	331-472M-E0	331-474M-E0	331-477M-E0	331-478M-E0	331-479M-E0
332-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 TV slot	332-471M-E0	332-472M-E0	332-474M-E0	332-477M-E0	332-478M-E0	332-479M-E0
333-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	333-471M-E0	333-472M-E0	333-474M-E0	333-477M-E0	333-478M-E0	333-479M-E0
334-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	334-471M-E0	334-472M-E0	334-474M-E0	334-477M-E0	334-478M-E0	334-479M-E0
335-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	335-471M-E0	335-472M-E0	335-474M-E0	335-477M-E0	335-478M-E0	335-479M-E0
338-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	338-471M-E0	338-472M-E0	338-474M-E0	338-477M-E0	338-478M-E0	338-479M-E0
320-		Cover plate 3 MEDIA slots	320-471M-E0	320-472M-E0	320-474M-E0	320-477M-E0	320-478M-E0	320-479M-E0
321-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	321-471M-E0	321-472M-E0	321-474M-E0	321-477M-E0	321-478M-E0	321-479M-E0
322-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	322-471M-E0	322-472M-E0	322-474M-E0	322-477M-E0	322-478M-E0	322-479M-E0
323-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	323-471M-E0	323-472M-E0	323-474M-E0	323-477M-E0	323-478M-E0	323-479M-E0
324-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	324-471M-E0	324-472M-E0	324-474M-E0	324-477M-E0	324-478M-E0	324-479M-E0
325-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	325-471M-E0	325-472M-E0	325-474M-E0	325-477M-E0	325-478M-E0	325-479M-E0
326-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	326-471M-E0	326-472M-E0	326-474M-E0	326-477M-E0	326-478M-E0	326-479M-E0
327-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	327-471M-E0	327-472M-E0	327-474M-E0	327-477M-E0	327-478M-E0	327-479M-E0
328-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	328-471M-E0	328-472M-E0	328-474M-E0	328-477M-E0	328-478M-E0	328-479M-E0
329-		Cover plate 2 sockets 2P+E + 1 TV slot	329-471M-E0	329-472M-E0	329-474M-E0	329-477M-E0	329-478M-E0	329-479M-E0
301-		Cover plate 1 MEDIA slot + 2 sockets 2P+E	301-471M-E0	301-472M-E0	301-474M-E0	301-477M-E0	301-478M-E0	301-479M-E0
RETAIL PRICE EX TAX			209,40 €	209,40 €	261,10 €	261,10 €	249,30 €	249,30 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

PLAN

TRIPLE VERTICAL COVER PLATES - PLAN - E0

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple vertical cover plates - Plan - E0

Triple cover plate dimensions:
80x222x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
353-		Cover plate 3 buttons slots	353-471M-E0	353-472M-E0	353-474M-E0	353-477M-E0	353-478M-E0	353-479M-E0
354-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	354-471M-E0	354-472M-E0	354-474M-E0	354-477M-E0	354-478M-E0	354-479M-E0
355-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	355-471M-E0	355-472M-E0	355-474M-E0	355-477M-E0	355-478M-E0	355-479M-E0
SYM 355-		Cover plate 2 buttons slots + 2 buttons slots + 1 button slot	SYM355- 471M-E0	SYM355- 472M-E0	SYM355- 474M-E0	SYM355- 477M-E0	SYM355- 478M-E0	SYM355- 479M-E0
356-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	356-471M-E0	356-472M-E0	356-474M-E0	356-477M-E0	356-478M-E0	356-479M-E0
360-		Cover plate 3 sockets 2P+E	360-471M-E0	360-472M-E0	360-474M-E0	360-477M-E0	360-478M-E0	360-479M-E0
361-		Cover plate 1 button slot + 2 sockets 2P+E	361-471M-E0	361-472M-E0	361-474M-E0	361-477M-E0	361-478M-E0	361-479M-E0
362-		Cover plate 2 buttons slots + 2 sockets 2P+E	362-471M-E0	362-472M-E0	362-474M-E0	362-477M-E0	362-478M-E0	362-479M-E0
363-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	363-471M-E0	363-472M-E0	363-474M-E0	363-477M-E0	363-478M-E0	363-479M-E0
387-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	387-471M-E0	387-472M-E0	387-474M-E0	387-477M-E0	387-478M-E0	387-479M-E0
364-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	364-471M-E0	364-472M-E0	364-474M-E0	364-477M-E0	364-478M-E0	364-479M-E0
365-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	365-471M-E0	365-472M-E0	365-474M-E0	365-477M-E0	365-478M-E0	365-479M-E0
376-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	376-471M-E0	376-472M-E0	376-474M-E0	376-477M-E0	376-478M-E0	376-479M-E0
366-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	366-471M-E0	366-472M-E0	366-474M-E0	366-477M-E0	366-478M-E0	366-479M-E0
367-		Cover plate 1 button slot + 2 buttons slots + 1 socket 2P+E	367-471M-E0	367-472M-E0	367-474M-E0	367-477M-E0	367-478M-E0	367-479M-E0
357-		Cover plate 1 button slot + 1 double USB charger slot + 1 socket 2P+E	357-471M-E0	357-472M-E0	357-474M-E0	357-477M-E0	357-478M-E0	357-479M-E0
358-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	358-471M-E0	358-472M-E0	358-474M-E0	358-477M-E0	358-478M-E0	358-479M-E0
351-		Cover plate 1 button slot + 1 socket 2P+E + double USB charger slot	351-471M-E0	351-472M-E0	351-474M-E0	351-477M-E0	351-478M-E0	351-479M-E0
352-		Cover plate 2 oblong slots + 1 socket 2P+E + 1 double USB charger slot	352-471M-E0	352-472M-E0	352-474M-E0	352-477M-E0	352-478M-E0	352-479M-E0
RETAIL PRICE EX TAX			209,40 €	209,40 €	261,10 €	261,10 €	249,30 €	249,30 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

PLAN

TRIPLE VERTICAL COVER PLATES - PLAN - E0

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple vertical cover plates - Plan - E0			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
Triple cover plate dimensions: 80x222x5mm			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
390-		Cover plate 1 double charger USB slot + 1 MEDIA slot + 2 MEDIA slots	390-471M-E0	390-472M-E0	390-474M-E0	390-477M-E0	390-478M-E0	390-479M-E0
391-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 button slot	391-471M-E0	391-472M-E0	391-474M-E0	391-477M-E0	391-478M-E0	391-479M-E0
392-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	392-471M-E0	392-472M-E0	392-474M-E0	392-477M-E0	392-478M-E0	392-479M-E0
383-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	383-471M-E0	383-472M-E0	383-474M-E0	383-477M-E0	383-478M-E0	383-479M-E0
388-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	388-471M-E0	388-472M-E0	388-474M-E0	388-477M-E0	388-478M-E0	388-479M-E0
384-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	384-471M-E0	384-472M-E0	384-474M-E0	384-477M-E0	384-478M-E0	384-479M-E0
385-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	385-471M-E0	385-472M-E0	385-474M-E0	385-477M-E0	385-478M-E0	385-479M-E0
368-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	368-471M-E0	368-472M-E0	368-474M-E0	368-477M-E0	368-478M-E0	368-479M-E0
386-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 MEDIA slots	386-471M-E0	386-472M-E0	386-474M-E0	386-477M-E0	386-478M-E0	386-479M-E0
370-		Cover plate 3 MEDIA slots	370-471M-E0	370-472M-E0	370-474M-E0	370-477M-E0	370-478M-E0	370-479M-E0
371-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	371-471M-E0	371-472M-E0	371-474M-E0	371-477M-E0	371-478M-E0	371-479M-E0
372-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	372-471M-E0	372-472M-E0	372-474M-E0	372-477M-E0	372-478M-E0	372-479M-E0
373-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	373-471M-E0	373-472M-E0	373-474M-E0	373-477M-E0	373-478M-E0	373-479M-E0
374-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	374-471M-E0	374-472M-E0	374-474M-E0	374-477M-E0	374-478M-E0	374-479M-E0
375-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	375-471M-E0	375-472M-E0	375-474M-E0	375-477M-E0	375-478M-E0	375-479M-E0
378-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	378-471M-E0	378-472M-E0	378-474M-E0	378-477M-E0	378-478M-E0	378-479M-E0
380-		Cover plate 2 MEDIA slots + 1 double USB charger slot	380-471M-E0	380-472M-E0	380-474M-E0	380-477M-E0	380-478M-E0	380-479M-E0
381-		Cover plate 1 double charger USB slot + 2 MEDIA slots	381-471M-E0	381-472M-E0	381-474M-E0	381-477M-E0	381-478M-E0	381-479M-E0
RETAIL PRICE EX TAX			209,40 €	209,40 €	261,10 €	261,10 €	249,30 €	249,30 €

PLAN



E.1

E.2

E.3

- Empreintes Collection – Plan Series – Old bronze – 1 button

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

VOLUME



- Empreintes collection – Volume series – Old bronze – 1 button

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

VOLUME

SINGLE COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Single cover plates - Volume

Single cover plate dimensions:
80x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
		Recommended button color	471	472	474	477	478	479
131-		Cover plate 1 button slot for 230V mechanism	131-471M-E1	131-472M-E1	131-474M-E1	131-477M-E1	131-478M-E1	131-479M-E1
132-		Cover plate 2 buttons slots for 230V mechanism	132-471M-E1	132-472M-E1	132-474M-E1	132-477M-E1	132-478M-E1	132-479M-E1
RETAIL PRICE EX TAX			108,80 €	108,80 €	121,80 €	121,80 €	119,70 €	119,70 €
190-		Cover plate socket 2P+E	190-471M-E1	190-472M-E1	190-474M-E1	190-477M-E1	190-478M-E1	190-479M-E1
190-K		Cover plate schuko socket	190-471M-E1K	190-472M-E1K	190-474M-E1K	190-477M-E1K	190-478M-E1K	190-479M-E1K
RETAIL PRICE EX TAX			110,20 €	110,20 €	123,90 €	123,90 €	122,80 €	122,80 €
189-		Cover plate double USB charger slot	189-471M-E1	189-472M-E1	189-474M-E1	189-477M-E1	189-478M-E1	189-479M-E1
200-		Cover plate power delivery USB C slot	200-471M-E1	200-472M-E1	200-474M-E1	200-477M-E1	200-478M-E1	200-479M-E1
192-		Cover plate 1 MEDIA slot	192-471M-E1	192-472M-E1	192-474M-E1	192-477M-E1	192-478M-E1	192-479M-E1
193-		Cover plate 2 MEDIA slots	193-471M-E1	193-472M-E1	193-474M-E1	193-477M-E1	193-478M-E1	193-479M-E1
210-		Cover plate 1 TV slot + 1 RJ45 slot	210-471M-E1	210-472M-E1	210-474M-E1	210-477M-E1	210-478M-E1	210-479M-E1
194-		Cover plate 1 TV slot	194-471M-E1	194-472M-E1	194-474M-E1	194-477M-E1	194-478M-E1	194-479M-E1
196-		Cover plate TV/FM/SAT slots	196-471M-E1	196-472M-E1	196-474M-E1	196-477M-E1	196-478M-E1	196-479M-E1
198-		Cover plate for shutter	198-471M-E1	198-472M-E1	198-474M-E1	198-477M-E1	198-478M-E1	198-479M-E1
RETAIL PRICE EX TAX			114,40 €	114,40 €	125,90 €	125,90 €	124,80 €	124,80 €
187-		Cover plate thermostat + button	187-471M-E1	187-472M-E1	187-474M-E1	187-477M-E1	187-478M-E1	187-479M-E1
RETAIL PRICE EX TAX			170,40 €	170,40 €	181,90 €	181,90 €	177,60 €	177,60 €
191-		Cover plate rotary dimmer slot	191-471M-E1	191-472M-E1	191-474M-E1	191-477M-E1	191-478M-E1	191-479M-E1
RETAIL PRICE EX TAX			144,50 €	144,50 €	160,30 €	160,30 €	152,20 €	152,20 €
190-CL		Cover plate 2P+E socket with flap	190-471M-E1CL	190-472M-E1CL	190-474M-E1CL	190-477M-E1CL	190-478M-E1CL	190-479M-E1CL
190-CLK		Cover plate Schuko socket with flap	190-471M-E1CLK	190-472M-E1CLK	190-474M-E1CLK	190-477M-E1CLK	190-478M-E1CLK	190-479M-E1CLK
RETAIL PRICE EX TAX			220,40 €	220,40 €	247,80 €	247,80 €	245,60 €	245,60 €
190-S		Cover plate 1 swiss socket	190-471M-E1S	190-472M-E1S	190-474M-E1S	190-474M-E1S	190-478M-E1S	190-479M-E1S
190-DS		Cover plate 1 double swiss socket	190-471M-E1DS	190-472M-E1DS	190-474M-E1DS	190-474M-E1DS	190-478M-E1DS	190-479M-E1DS
190-I		Cover plate 1 bipasso socket	190-471M-E1I	190-472M-E1I	190-474M-E1I	190-474M-E1I	190-478M-E1I	190-479M-E1I
199-		Cover plate for 45x45 module	199-471M-E1	199-472M-E1	199-474M-E1	199-477M-E1	199-478M-E1	199-479M-E1
RETAIL PRICE EX TAX			110,20 €	110,20 €	123,90 €	123,90 €	122,80 €	122,80 €

E.1
E.2
E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

VOLUME

DOUBLE HORIZONTAL COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Volume

Double cover plate dimensions:
151x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
172-		Cover plate 2 buttons slots	172-471M-E1	172-472M-E1	172-474M-E1	172-477M-E1	172-478M-E1	172-479M-E1
177-		Cover plate 1 button + 2 buttons slots	177-471M-E1	177-472M-E1	177-474M-E1	177-477M-E1	177-478M-E1	177-479M-E1
SYM 177-		Cover plate 2 buttons + 1 button slots	SYM177-471M-E1	SYM177-472M-E1	SYM177-474M-E1	SYM177-477M-E1	SYM177-478M-E1	SYM177-479M-E1
174-		Cover plate 4 buttons slots	174-471M-E1	174-472M-E1	174-474M-E1	174-477M-E1	174-478M-E1	174-479M-E1
229-		Cover plate double USB charger slot + 2 buttons slots	229-471M-E1	229-472M-E1	229-474M-E1	229-477M-E1	229-478M-E1	229-479M-E1
236-		Cover plate 2 buttons slots + double USB charger slot	236-471M-E1	236-472M-E1	236-474M-E1	236-477M-E1	236-478M-E1	236-479M-E1
255-		Cover plate 1 TV slot + 1 double USB charger slot	255-471M-E1	255-472M-E1	255-474M-E1	255-477M-E1	255-478M-E1	255-479M-E1
256-		Cover plate 1 double USB charger slot + 1 MEDIA slot	256-471M-E1	256-472M-E1	256-474M-E1	256-477M-E1	256-478M-E1	256-479M-E1
257-		Cover plate 1 double USB charger slot + 1 TV	257-471M-E1	257-472M-E1	257-474M-E1	257-477M-E1	257-478M-E1	257-479M-E1
258-		Cover plate double USB charger slot + TV/FM/SAT slots	258-471M-E1	258-472M-E1	258-474M-E1	258-477M-E1	258-478M-E1	258-479M-E1
259-		Cover plate socket 2P+E + 1 double USB charger slot	259-471M-E1	259-472M-E1	259-474M-E1	259-477M-E1	259-478M-E1	259-479M-E1
260-		Cover plate double socket 2P+E	260-471M-E1	260-472M-E1	260-474M-E1	260-477M-E1	260-478M-E1	260-479M-E1
261-		Cover plate 1 button slot + 1 socket 2P+E	261-471M-E1	261-472M-E1	261-474M-E1	261-477M-E1	261-478M-E1	261-479M-E1
262-		Cover plate 2 buttons slots + 1 socket 2P+E	262-471M-E1	262-472M-E1	262-474M-E1	262-477M-E1	262-478M-E1	262-479M-E1
263-		Cover plate socket 2P+E + 1 MEDIA slot	263-471M-E1	263-472M-E1	263-474M-E1	263-477M-E1	263-478M-E1	263-479M-E1
264-		Cover plate 1 socket 2P+E + 2 MEDIA slots	264-471M-E1	264-472M-E1	264-474M-E1	264-477M-E1	264-478M-E1	264-479M-E1
265-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	265-471M-E1	265-472M-E1	265-474M-E1	265-477M-E1	265-478M-E1	265-479M-E1
266-		Cover plate 1 MEDIA slot + 1 MEDIA slot	266-471M-E1	266-472M-E1	266-474M-E1	266-477M-E1	266-478M-E1	266-479M-E1
267-		Cover plate 1 MEDIA slot + 2 MEDIA slots	267-471M-E1	267-472M-E1	267-474M-E1	267-477M-E1	267-478M-E1	267-479M-E1
268-		Cover plate 2 MEDIA slots + 2 MEDIA slots	268-471M-E1	268-472M-E1	268-474M-E1	268-477M-E1	268-478M-E1	268-479M-E1
269-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	269-471M-E1	269-472M-E1	269-474M-E1	269-477M-E1	269-478M-E1	269-479M-E1
270-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	270-471M-E1	270-472M-E1	270-474M-E1	270-477M-E1	270-478M-E1	270-479M-E1
271-		Cover plate 1 MEDIA slot + 1 TV slot	271-471M-E1	271-472M-E1	271-474M-E1	271-477M-E1	271-478M-E1	271-479M-E1
235-		Cover plate 1 MEDIA slot + 1 cable outlet slot	235-471M-E1	235-472M-E1	235-474M-E1	235-477M-E1	235-478M-E1	235-479M-E1
272-		Cover plate 1 socket 2P+E + 1 cable outlet slot	272-471M-E1	272-472M-E1	272-474M-E1	272-477M-E1	272-478M-E1	272-479M-E1
SYM 272-		Cover plate 1 cable outlet slot + 1 socket 2P+E	SYM272-471M-E1	SYM272-472M-E1	SYM272-474M-E1	SYM272-477M-E1	SYM272-478M-E1	SYM272-479M-E1
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

VOLUME

DOUBLE HORIZONTAL COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Volume

Double cover plate dimensions:
151x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
273-		Cover plate 1 TV slot + 1 MEDIA slot	273-471M-E1	273-472M-E1	273-474M-E1	273-477M-E1	273-478M-E1	273-479M-E1
274-		Cover plate TV/FM/SAT slot + 1 MEDIA slot	274-471M-E1	274-472M-E1	274-474M-E1	274-477M-E1	274-478M-E1	274-479M-E1
275-		Cover plate 1 button slot + double USB charger slot	275-471M-E1	275-472M-E1	275-474M-E1	275-477M-E1	275-478M-E1	275-479M-E1
276-		Cover plate 1 MEDIA slot + 1 socket 2P+E	276-471M-E1	276-472M-E1	276-474M-E1	276-477M-E1	276-478M-E1	276-479M-E1
279-		Cover plate 1 socket 2P+E + 1 TV slot	279-471M-E1	279-472M-E1	279-474M-E1	279-477M-E1	279-478M-E1	279-479M-E1
298-		Cover plate 1 MEDIA slot + 1 double USB charger slot	298-471M-E1	298-472M-E1	298-474M-E1	298-477M-E1	298-478M-E1	298-479M-E1
295-		Cover plate 1 double USB charger slot + 1 socket 2P+E	295-471M-E1	295-472M-E1	295-474M-E1	295-477M-E1	295-478M-E1	295-479M-E1
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €
260-CL		Cover plate double socket 2P+E with flap	260-471M-E1CL	260-472M-E1CL	260-474M-E1CL	260-477M-E1CL	260-478M-E1CL	260-479M-E1CL
260-CLK		Cover plate double schuko socket with flap	260-471M-E1CLK	260-472M-E1CLK	260-474M-E1CLK	260-477M-E1CLK	260-478M-E1CLK	260-479M-E1CLK
RETAIL PRICE EX TAX			394,40 €	394,40 €	456,80 €	456,80 €	451,40 €	451,40 €



EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

VOLUME

DOUBLE VERTICAL COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Double vertical cover plates - Volume

Double cover plate dimensions:
80x151x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
152-		Cover plate 2 buttons slots	152-471M-E1	152-472M-E1	152-474M-E1	152-477M-E1	152-478M-E1	152-479M-E1
155-		Cover plate 1 button + 2 buttons slots	155-471M-E1	155-472M-E1	155-474M-E1	155-477M-E1	155-478M-E1	155-479M-E1
SYM 155-		Cover plate 2 buttons + 1 button slots	SYM155-471M-E1	SYM155-472M-E1	SYM155-474M-E1	SYM155-477M-E1	SYM155-478M-E1	SYM155-479M-E1
154-		Cover plate 4 buttons slots	154-471M-E1	154-472M-E1	154-474M-E1	154-477M-E1	154-478M-E1	154-479M-E1
280-		Cover plate double socket 2P+E	280-471M-E1	280-472M-E1	280-474M-E1	280-477M-E1	280-478M-E1	280-479M-E1
281-		Cover plate 1 button slot + 1 socket 2P+E	281-471M-E1	281-472M-E1	281-474M-E1	281-477M-E1	281-478M-E1	281-479M-E1
282-		Cover plate 2 buttons slots + 1 socket 2P+E	282-471M-E1	282-472M-E1	282-474M-E1	282-477M-E1	282-478M-E1	282-479M-E1
293-		Cover plate 1 button slot + double USB charger slot	293-471M-E1	293-472M-E1	293-474M-E1	293-477M-E1	293-478M-E1	293-479M-E1
SYM 293-		Cover plate 1 double USB charger slot + 1 button slot	SYM293-471M-E1	SYM293-472M-E1	SYM293-474M-E1	SYM293-477M-E1	SYM293-478M-E1	SYM293-479M-E1
283-		Cover plate socket 2P+E + 1 MEDIA slot	283-471M-E1	283-472M-E1	283-474M-E1	283-477M-E1	283-478M-E1	283-479M-E1
284-		Cover plate 1 socket 2P+E + 2 MEDIA slots	284-471M-E1	284-472M-E1	284-474M-E1	284-477M-E1	284-478M-E1	284-479M-E1
285-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	285-471M-E1	285-472M-E1	285-474M-E1	285-477M-E1	285-478M-E1	285-479M-E1
286-		Cover plate 1 MEDIA slot + 1 MEDIA slot	286-471M-E1	286-472M-E1	286-474M-E1	286-477M-E1	286-478M-E1	286-479M-E1
287-		Cover plate 1 MEDIA slot + 2 MEDIA slots	287-471M-E1	287-472M-E1	287-474M-E1	287-477M-E1	287-478M-E1	287-479M-E1
288-		Cover plate 2 MEDIA slots + 2 MEDIA slots	288-471M-E1	288-472M-E1	288-474M-E1	288-477M-E1	288-478M-E1	288-479M-E1
289-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	289-471M-E1	289-472M-E1	289-474M-E1	289-477M-E1	289-478M-E1	289-479M-E1
290-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	290-471M-E1	290-472M-E1	290-474M-E1	290-477M-E1	290-478M-E1	290-479M-E1
292-		Cover plate 2 buttons slots + 1 MEDIA slot	292-471M-E1	292-472M-E1	292-474M-E1	292-477M-E1	292-478M-E1	292-479M-E1
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €

VOLUME



E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

VOLUME

TRIPLE HORIZONTAL COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Triple horizontal cover plates - Volume

Triple cover plate dimensions:
222x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
303-		Cover plate 3 buttons slots	303-471M-E1	303-472M-E1	303-474M-E1	303-477M-E1	303-478M-E1	303-479M-E1
304-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	304-471M-E1	304-472M-E1	304-474M-E1	304-477M-E1	304-478M-E1	304-479M-E1
305-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	305-471M-E1	305-472M-E1	305-474M-E1	305-477M-E1	305-478M-E1	305-479M-E1
306-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	306-471M-E1	306-472M-E1	306-474M-E1	306-477M-E1	306-478M-E1	306-479M-E1
311-		Cover plate 1 button slot + 2 sockets 2P+E	311-471M-E1	311-472M-E1	311-474M-E1	311-477M-E1	311-478M-E1	311-479M-E1
SYM311-		Cover plate 2 sockets 2P+E + 1 button slot	SYM311-471M-E1	SYM311-472M-E1	SYM311-474M-E1	SYM311-477M-E1	SYM311-478M-E1	SYM311-479M-E1
312-		Cover plate 2 buttons slots + 2 sockets 2P+E	312-471M-E1	312-472M-E1	312-474M-E1	312-477M-E1	312-478M-E1	312-479M-E1
316-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	316-471M-E1	316-472M-E1	316-474M-E1	316-477M-E1	316-478M-E1	316-479M-E1
341-		Cover plate 2 buttons slots + 1 socket 2P+E + 1 double USB charger slot	341-471M-E1	341-472M-E1	341-474M-E1	341-477M-E1	341-478M-E1	341-479M-E1
342-		Cover plate 1 socket 2P+E + 2 buttons slots + 1 button slot	342-471M-E1	342-472M-E1	342-474M-E1	342-477M-E1	342-478M-E1	342-479M-E1
343-		Cover plate 1 double USB charger slot + 1 socket 2P+E + 1 button slot	343-471M-E1	343-472M-E1	343-474M-E1	343-477M-E1	343-478M-E1	343-479M-E1
345-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	345-471M-E1	345-472M-E1	345-474M-E1	345-477M-E1	345-478M-E1	345-479M-E1
346-		Cover plate 1 button slot + 1 socket 2P+E + 1 double USB charger slot	346-471M-E1	346-472M-E1	346-474M-E1	346-477M-E1	346-478M-E1	346-479M-E1
308-		Cover plate socket 2P+E + 1 double USB charger slot + 1 button slot	308-471M-E1	308-472M-E1	308-474M-E1	308-477M-E1	308-478M-E1	308-479M-E1
309-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	309-471M-E1	309-472M-E1	309-474M-E1	309-477M-E1	309-478M-E1	309-479M-E1
310-		Cover plate 3 sockets 2P+E	310-471M-E1	310-472M-E1	310-474M-E1	310-477M-E1	310-478M-E1	310-479M-E1
313-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	313-471M-E1	313-472M-E1	313-474M-E1	313-477M-E1	313-478M-E1	313-479M-E1
337-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	337-471M-E1	337-472M-E1	337-474M-E1	337-477M-E1	337-478M-E1	337-479M-E1
314-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	314-471M-E1	314-472M-E1	314-474M-E1	314-477M-E1	314-478M-E1	314-479M-E1
315-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	315-471M-E1	315-472M-E1	315-474M-E1	315-477M-E1	315-478M-E1	315-479M-E1
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

VOLUME

TRIPLE HORIZONTAL COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Triple horizontal cover plates - Volume

Triple cover plate dimensions:
222x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
344-		Cover plate 2 sockets 2P+E + 1 cable outlet slot	344-471M-E1	344-472M-E1	344-474M-E1	344-477M-E1	344-478M-E1	344-479M-E1
319-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 TV slot	319-471M-E1	319-472M-E1	319-474M-E1	319-477M-E1	319-478M-E1	319-479M-E1
330-		Cover plate 2 MEDIA slots + 1 double USB charger slot	330-471M-E1	330-472M-E1	330-474M-E1	330-477M-E1	330-478M-E1	330-479M-E1
331-		Cover plate 1 double charger USB slot + 2 MEDIA slots	331-471M-E1	331-472M-E1	331-474M-E1	331-477M-E1	331-478M-E1	331-479M-E1
332-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 TV slot	332-471M-E1	332-472M-E1	332-474M-E1	332-477M-E1	332-478M-E1	332-479M-E1
333-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	333-471M-E1	333-472M-E1	333-474M-E1	333-477M-E1	333-478M-E1	333-479M-E1
334-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	334-471M-E1	334-472M-E1	334-474M-E1	334-477M-E1	334-478M-E1	334-479M-E1
335-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	335-471M-E1	335-472M-E1	335-474M-E1	335-477M-E1	335-478M-E1	335-479M-E1
338-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	338-471M-E1	338-472M-E1	338-474M-E1	338-477M-E1	338-478M-E1	338-479M-E1
320-		Cover plate 3 MEDIA slots	320-471M-E1	320-472M-E1	320-474M-E1	320-477M-E1	320-478M-E1	320-479M-E1
321-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	321-471M-E1	321-472M-E1	321-474M-E1	321-477M-E1	321-478M-E1	321-479M-E1
322-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	322-471M-E1	322-472M-E1	322-474M-E1	322-477M-E1	322-478M-E1	322-479M-E1
323-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	323-471M-E1	323-472M-E1	323-474M-E1	323-477M-E1	323-478M-E1	323-479M-E1
324-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	324-471M-E1	324-472M-E1	324-474M-E1	324-477M-E1	324-478M-E1	324-479M-E1
325-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	325-471M-E1	325-472M-E1	325-474M-E1	325-477M-E1	325-478M-E1	325-479M-E1
326-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	326-471M-E1	326-472M-E1	326-474M-E1	326-477M-E1	326-478M-E1	326-479M-E1
327-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	327-471M-E1	327-472M-E1	327-474M-E1	327-477M-E1	327-478M-E1	327-479M-E1
328-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	328-471M-E1	328-472M-E1	328-474M-E1	328-477M-E1	328-478M-E1	328-479M-E1
329-		Cover plate 2 sockets 2P+E + 1 TV slot	329-471M-E1	329-472M-E1	329-474M-E1	329-477M-E1	329-478M-E1	329-479M-E1
301-		Cover plate 1 MEDIA slot + 2 sockets 2P+E	301-471M-E1	301-472M-E1	301-474M-E1	301-477M-E1	301-478M-E1	301-479M-E1
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

VOLUME

TRIPE VERTICAL COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Tripe vertical cover plates - Volume

Triple cover plate dimensions:
80x222x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
353-		Cover plate 3 buttons slots	353-471M-E1	353-472M-E1	353-474M-E1	353-477M-E1	353-478M-E1	353-479M-E1
354-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	354-471M-E1	354-472M-E1	354-474M-E1	354-477M-E1	354-478M-E1	354-479M-E1
355-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	355-471M-E1	355-472M-E1	355-474M-E1	355-477M-E1	355-478M-E1	355-479M-E1
SYM 355-		Cover plate 2 buttons slots + 2 buttons slots + 1 button slot	SYM355-471M-E1	SYM355-472M-E1	SYM355-474M-E1	SYM355-477M-E1	SYM355-478M-E1	SYM355-479M-E1
356-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	356-471M-E1	356-472M-E1	356-474M-E1	356-477M-E1	356-478M-E1	356-479M-E1
360-		Cover plate 3 sockets 2P+E	360-471M-E1	360-472M-E1	360-474M-E1	360-477M-E1	360-478M-E1	360-479M-E1
361-		Cover plate 1 button slot + 2 sockets 2P+E	361-471M-E1	361-472M-E1	361-474M-E1	361-477M-E1	361-478M-E1	361-479M-E1
362-		Cover plate 2 buttons slots + 2 sockets 2P+E	362-471M-E1	362-472M-E1	362-474M-E1	362-477M-E1	362-478M-E1	362-479M-E1
363-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	363-471M-E1	363-472M-E1	363-474M-E1	363-477M-E1	363-478M-E1	363-479M-E1
387-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	387-471M-E1	387-472M-E1	387-474M-E1	387-477M-E1	387-478M-E1	387-479M-E1
364-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	364-471M-E1	364-472M-E1	364-474M-E1	364-477M-E1	364-478M-E1	364-479M-E1
365-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	365-471M-E1	365-472M-E1	365-474M-E1	365-477M-E1	365-478M-E1	365-479M-E1
376-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	376-471M-E1	376-472M-E1	376-474M-E1	376-477M-E1	376-478M-E1	376-479M-E1
366-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	366-471M-E1	366-472M-E1	366-474M-E1	366-477M-E1	366-478M-E1	366-479M-E1
367-		Cover plate 1 button slot + 2 buttons slots + 1 socket 2P+E	367-471M-E1	367-472M-E1	367-474M-E1	367-477M-E1	367-478M-E1	367-479M-E1
357-		Cover plate 1 button slot + 1 double USB charger slot + 1 socket 2P+E	357-471M-E1	357-472M-E1	357-474M-E1	357-477M-E1	357-478M-E1	357-479M-E1
358-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	358-471M-E1	358-472M-E1	358-474M-E1	358-477M-E1	358-478M-E1	358-479M-E1
351-		Cover plate 1 button slot + 1 socket 2P+E + double USB charger slot	351-471M-E1	351-472M-E1	351-474M-E1	351-477M-E1	351-478M-E1	351-479M-E1
352-		Cover plate 2 oblong slots + 1 socket 2P+E + 1 double USB charger slot	352-471M-E1	352-472M-E1	352-474M-E1	352-477M-E1	352-478M-E1	352-479M-E1
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

VOLUME

TRIPE VERTICAL COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Tripe vertical cover plates - Volume

Triple cover plate dimensions:
80x222x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
		Recommended button color	471	472	474	477	478	479
		Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass	
390-		Cover plate 1 double charger USB slot + 1 MEDIA slot + 2 MEDIA slots	390-471M-E1	390-472M-E1	390-474M-E1	390-477M-E1	390-478M-E1	390-479M-E1
391-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 button slot	391-471M-E1	391-472M-E1	391-474M-E1	391-477M-E1	391-478M-E1	391-479M-E1
392-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	392-471M-E1	392-472M-E1	392-474M-E1	392-477M-E1	392-478M-E1	392-479M-E1
383-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	383-471M-E1	383-472M-E1	383-474M-E1	383-477M-E1	383-478M-E1	383-479M-E1
388-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	388-471M-E1	388-472M-E1	388-474M-E1	388-477M-E1	388-478M-E1	388-479M-E1
384-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	384-471M-E1	384-472M-E1	384-474M-E1	384-477M-E1	384-478M-E1	384-479M-E1
385-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	385-471M-E1	385-472M-E1	385-474M-E1	385-477M-E1	385-478M-E1	385-479M-E1
368-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	368-471M-E1	368-472M-E1	368-474M-E1	368-477M-E1	368-478M-E1	368-479M-E1
386-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 MEDIA slots	386-471M-E1	386-472M-E1	386-474M-E1	386-477M-E1	386-478M-E1	386-479M-E1
370-		Cover plate 3 MEDIA slots	370-471M-E1	370-472M-E1	370-474M-E1	370-477M-E1	370-478M-E1	370-479M-E1
371-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	371-471M-E1	371-472M-E1	371-474M-E1	371-477M-E1	371-478M-E1	371-479M-E1
372-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	372-471M-E1	372-472M-E1	372-474M-E1	372-477M-E1	372-478M-E1	372-479M-E1
373-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	373-471M-E1	373-472M-E1	373-474M-E1	373-477M-E1	373-478M-E1	373-479M-E1
374-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	374-471M-E1	374-472M-E1	374-474M-E1	374-477M-E1	374-478M-E1	374-479M-E1
375-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	375-471M-E1	375-472M-E1	375-474M-E1	375-477M-E1	375-478M-E1	375-479M-E1
378-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	378-471M-E1	378-472M-E1	378-474M-E1	378-477M-E1	378-478M-E1	378-479M-E1
380-		Cover plate 2 MEDIA slots + 1 double USB charger slot	380-471M-E1	380-472M-E1	380-474M-E1	380-477M-E1	380-478M-E1	380-479M-E1
381-		Cover plate 1 double charger USB slot + 2 MEDIA slots	381-471M-E1	381-472M-E1	381-474M-E1	381-477M-E1	381-478M-E1	381-479M-E1
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

E.1

E.2

E.3

ANGLE



- Empreintes collection – Angle series – Satin brass – 1 button

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

ANGLE

SINGLE COVER PLATES - ANGLE - E2

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Single cover plates - Angle

Single cover plate dimensions:
80x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
		Recommended button color	471	472	474	477	478	479
			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
131-		Cover plate 1 button slot for 230V mechanism	131-471M-E2	131-472M-E2	131-474M-E2	131-477M-E2	131-478M-E2	131-479M-E2
132-		Cover plate 2 buttons slots for 230V mechanism	132-471M-E2	132-472M-E2	132-474M-E2	132-477M-E2	132-478M-E2	132-479M-E2
RETAIL PRICE EX TAX			108,80 €	108,80 €	121,80 €	121,80 €	119,70 €	119,70 €
190-		Cover plate socket 2P+E	190-471M-E2	190-472M-E2	190-474M-E2	190-477M-E2	190-478M-E2	190-479M-E2
190-K		Cover plate schuko socket	190-471M-E2K	190-472M-E2K	190-474M-E2K	190-477M-E2K	190-478M-E2K	190-479M-E2K
RETAIL PRICE EX TAX			110,20 €	110,20 €	123,90 €	123,90 €	122,80 €	122,80 €
189-		Cover plate double USB charger slot	189-471M-E2	189-472M-E2	189-474M-E2	189-477M-E2	189-478M-E2	189-479M-E2
200-		Cover plate power delivery USB C slot	200-471M-E2	200-472M-E2	200-474M-E2	200-477M-E2	200-478M-E2	200-479M-E2
192-		Cover plate 1 MEDIA slot	192-471M-E2	192-472M-E2	192-474M-E2	192-477M-E2	192-478M-E2	192-479M-E2
193-		Cover plate 2 MEDIA slots	193-471M-E2	193-472M-E2	193-474M-E2	193-477M-E2	193-478M-E2	193-479M-E2
210-		Cover plate 1 TV slot + 1 RJ45 slot	210-471M-E2	210-472M-E2	210-474M-E2	210-477M-E2	210-478M-E2	210-479M-E2
194-		Cover plate 1 TV slot	194-471M-E2	194-472M-E2	194-474M-E2	194-477M-E2	194-478M-E2	194-479M-E2
196-		Cover plate TV/FM/SAT slots	196-471M-E2	196-472M-E2	196-474M-E2	196-477M-E2	196-478M-E2	196-479M-E2
198-		Cover plate for shutter	198-471M-E2	198-472M-E2	198-474M-E2	198-477M-E2	198-478M-E2	198-479M-E2
RETAIL PRICE EX TAX			114,40 €	114,40 €	125,90 €	125,90 €	124,80 €	124,80 €
187-		Cover plate thermostat + button	187-471M-E2	187-472M-E2	187-474M-E2	187-477M-E2	187-478M-E2	187-479M-E2
RETAIL PRICE EX TAX			170,40 €	170,40 €	181,90 €	181,90 €	177,60 €	177,60 €
191-		Cover plate rotary dimmer slot	191-471M-E2	191-472M-E2	191-474M-E2	191-477M-E2	191-478M-E2	191-479M-E2
RETAIL PRICE EX TAX			144,50 €	144,50 €	160,30 €	160,30 €	152,20 €	152,20 €
190-CL		Cover plate 2P+E socket with flap	190-471M-E2CL	190-472M-E2CL	190-474M-E2CL	190-477M-E2CL	190-478M-E2CL	190-479M-E2CL
190-CLK		Cover plate Schuko socket with flap	190-471M-E2CLK	190-472M-E2CLK	190-474M-E2CLK	190-477M-E2CLK	190-478M-E2CLK	190-479M-E2CLK
RETAIL PRICE EX TAX			220,40 €	220,40 €	247,80 €	247,80 €	245,60 €	245,60 €
190-S		Cover plate 1 swiss socket	190-471M-E2S	190-472M-E2S	190-474M-E2S	190-474M-E2S	190-478M-E2S	190-479M-E2S
190-DS		Cover plate 1 double swiss socket	190-471M-E2DS	190-472M-E2DS	190-474M-E2DS	190-474M-E2DS	190-478M-E2DS	190-479M-E2DS
190-I		Cover plate 1 bipasso socket	190-471M-E2I	190-472M-E2I	190-474M-E2I	190-474M-E2I	190-478M-E2I	190-479M-E2I
199-		Cover plate for 45x45 module	199-471M-E2	199-472M-E2	199-474M-E2	199-477M-E2	199-478M-E2	199-479M-E2
RETAIL PRICE EX TAX			110,20 €	110,20 €	123,90 €	123,90 €	122,80 €	122,80 €

E.1

E.2

E.3

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

DOUBLE HORIZONTAL COVER PLATES - ANGLE - E2

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Angle

Double cover plate dimensions:
151x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
172-		Cover plate 2 buttons slots	172-471M-E2	172-472M-E2	172-474M-E2	172-477M-E2	172-478M-E2	172-479M-E2
177-		Cover plate 1 button + 2 buttons slots	177-471M-E2	177-472M-E2	177-474M-E2	177-477M-E2	177-478M-E2	177-479M-E2
SYM 177-		Cover plate 2 buttons + 1 button slots	SYM177-471M-E2	SYM177-472M-E2	SYM177-474M-E2	SYM177-477M-E2	SYM177-478M-E2	SYM177-479M-E2
174-		Cover plate 4 buttons slots	174-471M-E2	174-472M-E2	174-474M-E2	174-477M-E2	174-478M-E2	174-479M-E2
229-		Cover plate double USB charger slot + 2 buttons slots	229-471M-E2	229-472M-E2	229-474M-E2	229-477M-E2	229-478M-E2	229-479M-E2
236-		Cover plate 2 buttons slots + double USB charger slot	236-471M-E2	236-472M-E2	236-474M-E2	236-477M-E2	236-478M-E2	236-479M-E2
255-		Cover plate 1 TV slot + 1 double USB charger slot	255-471M-E2	255-472M-E2	255-474M-E2	255-477M-E2	255-478M-E2	255-479M-E2
256-		Cover plate 1 double USB charger slot + 1 MEDIA slot	256-471M-E2	256-472M-E2	256-474M-E2	256-477M-E2	256-478M-E2	256-479M-E2
257-		Cover plate 1 double USB charger slot + 1 TV	257-471M-E2	257-472M-E2	257-474M-E2	257-477M-E2	257-478M-E2	257-479M-E2
258-		Cover plate double USB charger slot + TV/FM/SAT slots	258-471M-E2	258-472M-E2	258-474M-E2	258-477M-E2	258-478M-E2	258-479M-E2
259-		Cover plate socket 2P+E + 1 double USB charger slot	259-471M-E2	259-472M-E2	259-474M-E2	259-477M-E2	259-478M-E2	259-479M-E2
260-		Cover plate double socket 2P+E	260-471M-E2	260-472M-E2	260-474M-E2	260-477M-E2	260-478M-E2	260-479M-E2
261-		Cover plate 1 button slot + 1 socket 2P+E	261-471M-E2	261-472M-E2	261-474M-E2	261-477M-E2	261-478M-E2	261-479M-E2
262-		Cover plate 2 buttons slots + 1 socket 2P+E	262-471M-E2	262-472M-E2	262-474M-E2	262-477M-E2	262-478M-E2	262-479M-E2
263-		Cover plate socket 2P+E + 1 MEDIA slot	263-471M-E2	263-472M-E2	263-474M-E2	263-477M-E2	263-478M-E2	263-479M-E2
264-		Cover plate 1 socket 2P+E + 2 MEDIA slots	264-471M-E2	264-472M-E2	264-474M-E2	264-477M-E2	264-478M-E2	264-479M-E2
265-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	265-471M-E2	265-472M-E2	265-474M-E2	265-477M-E2	265-478M-E2	265-479M-E2
266-		Cover plate 1 MEDIA slot + 1 MEDIA slot	266-471M-E2	266-472M-E2	266-474M-E2	266-477M-E2	266-478M-E2	266-479M-E2
267-		Cover plate 1 MEDIA slot + 2 MEDIA slots	267-471M-E2	267-472M-E2	267-474M-E2	267-477M-E2	267-478M-E2	267-479M-E2
268-		Cover plate 2 MEDIA slots + 2 MEDIA slots	268-471M-E2	268-472M-E2	268-474M-E2	268-477M-E2	268-478M-E2	268-479M-E2
269-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	269-471M-E2	269-472M-E2	269-474M-E2	269-477M-E2	269-478M-E2	269-479M-E2
270-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	270-471M-E2	270-472M-E2	270-474M-E2	270-477M-E2	270-478M-E2	270-479M-E2
271-		Cover plate 1 MEDIA slot + 1 TV slot	271-471M-E2	271-472M-E2	271-474M-E2	271-477M-E2	271-478M-E2	271-479M-E2
235-		Cover plate 1 MEDIA slot + 1 cable outlet slot	235-471M-E2	235-472M-E2	235-474M-E2	235-477M-E2	235-478M-E2	235-479M-E2
272-		Cover plate 1 socket 2P+E + 1 cable outlet slot	272-471M-E2	272-472M-E2	272-474M-E2	272-477M-E2	272-478M-E2	272-479M-E2
SYM 272-		Cover plate 1 cable outlet slot + 1 socket 2P+E	SYM272-471M-E2	SYM272-472M-E2	SYM272-474M-E2	SYM272-477M-E2	SYM272-478M-E2	SYM272-479M-E2
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

DOUBLE HORIZONTAL COVER PLATES - ANGLE - E2

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Angle

Double cover plate dimensions:
151x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
273-		Cover plate 1 TV slot + 1 MEDIA slot	273-471M-E2	273-472M-E2	273-474M-E2	273-477M-E2	273-478M-E2	273-479M-E2
274-		Cover plate TV/FM/SAT slot + 1 MEDIA slot	274-471M-E2	274-472M-E2	274-474M-E2	274-477M-E2	274-478M-E2	274-479M-E2
275-		Cover plate 1 button slot + double USB charger slot	275-471M-E2	275-472M-E2	275-474M-E2	275-477M-E2	275-478M-E2	275-479M-E2
276-		Cover plate 1 MEDIA slot + 1 socket 2P+E	276-471M-E2	276-472M-E2	276-474M-E2	276-477M-E2	276-478M-E2	276-479M-E2
279-		Cover plate 1 socket 2P+E + 1 TV slot	279-471M-E2	279-472M-E2	279-474M-E2	279-477M-E2	279-478M-E2	279-479M-E2
298-		Cover plate 1 MEDIA slot + 1 double USB charger slot	298-471M-E2	298-472M-E2	298-474M-E2	298-477M-E2	298-478M-E2	298-479M-E2
295-		Cover plate 1 double USB charger slot + 1 socket 2P+E	295-471M-E2	295-472M-E2	295-474M-E2	295-477M-E2	295-478M-E2	295-479M-E2
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €
260-CL		Cover plate double socket 2P+E with flap	260-471M-E2CL	260-472M-E2CL	260-474M-E2CL	260-477M-E2CL	260-478M-E2CL	260-479M-E2CL
260-CLK		Cover plate double schuko socket with flap	260-471M-E2CLK	260-472M-E2CLK	260-474M-E2CLK	260-477M-E2CLK	260-478M-E2CLK	260-479M-E2CLK
RETAIL PRICE EX TAX			394,40 €	394,40 €	456,80 €	456,80 €	451,40 €	451,40 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

DOUBLE VERTICAL COVER PLATES - **ANGLE - E2**

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double vertical cover plates - **Angle**

Double cover plate dimensions:
80x151x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
		Recommended button color	471	472	474	477	478	479
		Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass	
152-		Cover plate 2 buttons slots	152-471M-E2	152-472M-E2	152-474M-E2	152-477M-E2	152-478M-E2	152-479M-E2
155-		Cover plate 1 button + 2 buttons slots	155-471M-E2	155-472M-E2	155-474M-E2	155-477M-E2	155-478M-E2	155-479M-E2
SYM 155-		Cover plate 2 buttons + 1 button slots	SYM155-471M-E2	SYM155-472M-E2	SYM155-474M-E2	SYM155-477M-E2	SYM155-478M-E2	SYM155-479M-E2
154-		Cover plate 4 buttons slots	154-471M-E2	154-472M-E2	154-474M-E2	154-477M-E2	154-478M-E2	154-479M-E2
280-		Cover plate double socket 2P+E	280-471M-E2	280-472M-E2	280-474M-E2	280-477M-E2	280-478M-E2	280-479M-E2
281-		Cover plate 1 button slot + 1 socket 2P+E	281-471M-E2	281-472M-E2	281-474M-E2	281-477M-E2	281-478M-E2	281-479M-E2
282-		Cover plate 2 buttons slots + 1 socket 2P+E	282-471M-E2	282-472M-E2	282-474M-E2	282-477M-E2	282-478M-E2	282-479M-E2
293-		Cover plate 1 button slot + double USB charger slot	293-471M-E2	293-472M-E2	293-474M-E2	293-477M-E2	293-478M-E2	293-479M-E2
SYM 293-		Cover plate 1 double USB charger slot + 1 button slot	SYM293-471M-E2	SYM293-472M-E2	SYM293-474M-E2	SYM293-477M-E2	SYM293-478M-E2	SYM293-479M-E2
283-		Cover plate socket 2P+E + 1 MEDIA slot	283-471M-E2	283-472M-E2	283-474M-E2	283-477M-E2	283-478M-E2	283-479M-E2
284-		Cover plate 1 socket 2P+E + 2 MEDIA slots	284-471M-E2	284-472M-E2	284-474M-E2	284-477M-E2	284-478M-E2	284-479M-E2
285-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	285-471M-E2	285-472M-E2	285-474M-E2	285-477M-E2	285-478M-E2	285-479M-E2
286-		Cover plate 1 MEDIA slot + 1 MEDIA slot	286-471M-E2	286-472M-E2	286-474M-E2	286-477M-E2	286-478M-E2	286-479M-E2
287-		Cover plate 1 MEDIA slot + 2 MEDIA slots	287-471M-E2	287-472M-E2	287-474M-E2	287-477M-E2	287-478M-E2	287-479M-E2
288-		Cover plate 2 MEDIA slots + 2 MEDIA slots	288-471M-E2	288-472M-E2	288-474M-E2	288-477M-E2	288-478M-E2	288-479M-E2
289-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	289-471M-E2	289-472M-E2	289-474M-E2	289-477M-E2	289-478M-E2	289-479M-E2
290-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	290-471M-E2	290-472M-E2	290-474M-E2	290-477M-E2	290-478M-E2	290-479M-E2
292-		Cover plate 2 buttons slots + 1 MEDIA slot	292-471M-E2	292-472M-E2	292-474M-E2	292-477M-E2	292-478M-E2	292-479M-E2
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

TRIPLE HORIZONTAL COVER PLATES - ANGLE - E2

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Triple horizontal cover plates - Angle

Triple cover plate dimensions:
222x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
303-		Cover plate 3 buttons slots	303-471M-E2	303-472M-E2	303-474M-E2	303-477M-E2	303-478M-E2	303-479M-E2
304-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	304-471M-E2	304-472M-E2	304-474M-E2	304-477M-E2	304-478M-E2	304-479M-E2
305-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	305-471M-E2	305-472M-E2	305-474M-E2	305-477M-E2	305-478M-E2	305-479M-E2
306-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	306-471M-E2	306-472M-E2	306-474M-E2	306-477M-E2	306-478M-E2	306-479M-E2
311-		Cover plate 1 button slot + 2 sockets 2P+E	311-471M-E2	311-472M-E2	311-474M-E2	311-477M-E2	311-478M-E2	311-479M-E2
SYM 311-		Cover plate 2 sockets 2P+E + 1 button slot	SYM311-471M-E2	SYM311-472M-E2	SYM311-474M-E2	SYM311-477M-E2	SYM311-478M-E2	SYM311-479M-E2
312-		Cover plate 2 buttons slots + 2 sockets 2P+E	312-471M-E2	312-472M-E2	312-474M-E2	312-477M-E2	312-478M-E2	312-479M-E2
316-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	316-471M-E2	316-472M-E2	316-474M-E2	316-477M-E2	316-478M-E2	316-479M-E2
341-		Cover plate 2 buttons slots + 1 socket 2P+E + 1 double USB charger slot	341-471M-E2	341-472M-E2	341-474M-E2	341-477M-E2	341-478M-E2	341-479M-E2
342-		Cover plate 1 socket 2P+E + 2 buttons slots + 1 button slot	342-471M-E2	342-472M-E2	342-474M-E2	342-477M-E2	342-478M-E2	342-479M-E2
343-		Cover plate 1 double USB charger slot + 1 socket 2P+E + 1 button slot	343-471M-E2	343-472M-E2	343-474M-E2	343-477M-E2	343-478M-E2	343-479M-E2
345-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	345-471M-E2	345-472M-E2	345-474M-E2	345-477M-E2	345-478M-E2	345-479M-E2
346-		Cover plate 1 button slot + 1 socket 2P+E + 1 double USB charger slot	346-471M-E2	346-472M-E2	346-474M-E2	346-477M-E2	346-478M-E2	346-479M-E2
308-		Cover plate socket 2P+E + 1 double USB charger slot + 1 button slot	308-471M-E2	308-472M-E2	308-474M-E2	308-477M-E2	308-478M-E2	308-479M-E2
309-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	309-471M-E2	309-472M-E2	309-474M-E2	309-477M-E2	309-478M-E2	309-479M-E2
310-		Cover plate 3 sockets 2P+E	310-471M-E2	310-472M-E2	310-474M-E2	310-477M-E2	310-478M-E2	310-479M-E2
313-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	313-471M-E2	313-472M-E2	313-474M-E2	313-477M-E2	313-478M-E2	313-479M-E2
337-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	337-471M-E2	337-472M-E2	337-474M-E2	337-477M-E2	337-478M-E2	337-479M-E2
314-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	314-471M-E2	314-472M-E2	314-474M-E2	314-477M-E2	314-478M-E2	314-479M-E2
315-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	315-471M-E2	315-472M-E2	315-474M-E2	315-477M-E2	315-478M-E2	315-479M-E2
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

E.1
E.2
E.3

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

TRIPLE HORIZONTAL COVER PLATES - **ANGLE - E2**

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple horizontal cover plates - **Angle**

Triple cover plate dimensions:
222x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
344-		Cover plate 2 sockets 2P+E + 1 cable outlet slot	344-471M-E2	344-472M-E2	344-474M-E2	344-477M-E2	344-478M-E2	344-479M-E2
319-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 TV slot	319-471M-E2	319-472M-E2	319-474M-E2	319-477M-E2	319-478M-E2	319-479M-E2
330-		Cover plate 2 MEDIA slots + 1 double USB charger slot	330-471M-E2	330-472M-E2	330-474M-E2	330-477M-E2	330-478M-E2	330-479M-E2
331-		Cover plate 1 double charger USB slot + 2 MEDIA slots	331-471M-E2	331-472M-E2	331-474M-E2	331-477M-E2	331-478M-E2	331-479M-E2
332-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 TV slot	332-471M-E2	332-472M-E2	332-474M-E2	332-477M-E2	332-478M-E2	332-479M-E2
333-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	333-471M-E2	333-472M-E2	333-474M-E2	333-477M-E2	333-478M-E2	333-479M-E2
334-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	334-471M-E2	334-472M-E2	334-474M-E2	334-477M-E2	334-478M-E2	334-479M-E2
335-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	335-471M-E2	335-472M-E2	335-474M-E2	335-477M-E2	335-478M-E2	335-479M-E2
338-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	338-471M-E2	338-472M-E2	338-474M-E2	338-477M-E2	338-478M-E2	338-479M-E2
320-		Cover plate 3 MEDIA slots	320-471M-E2	320-472M-E2	320-474M-E2	320-477M-E2	320-478M-E2	320-479M-E2
321-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	321-471M-E2	321-472M-E2	321-474M-E2	321-477M-E2	321-478M-E2	321-479M-E2
322-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	322-471M-E2	322-472M-E2	322-474M-E2	322-477M-E2	322-478M-E2	322-479M-E2
323-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	323-471M-E2	323-472M-E2	323-474M-E2	323-477M-E2	323-478M-E2	323-479M-E2
324-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	324-471M-E2	324-472M-E2	324-474M-E2	324-477M-E2	324-478M-E2	324-479M-E2
325-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	325-471M-E2	325-472M-E2	325-474M-E2	325-477M-E2	325-478M-E2	325-479M-E2
326-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	326-471M-E2	326-472M-E2	326-474M-E2	326-477M-E2	326-478M-E2	326-479M-E2
327-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	327-471M-E2	327-472M-E2	327-474M-E2	327-477M-E2	327-478M-E2	327-479M-E2
328-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	328-471M-E2	328-472M-E2	328-474M-E2	328-477M-E2	328-478M-E2	328-479M-E2
329-		Cover plate 2 sockets 2P+E + 1 TV slot	329-471M-E2	329-472M-E2	329-474M-E2	329-477M-E2	329-478M-E2	329-479M-E2
301-		Cover plate 1 MEDIA slot + 2 sockets 2P+E	301-471M-E2	301-472M-E2	301-474M-E2	301-477M-E2	301-478M-E2	301-479M-E2
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

TRIPLE VERTICAL COVER PLATES - ANGLE - E2

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple vertical cover plates - Angle

Triple cover plate dimensions:
80x222x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
353-		Cover plate 3 buttons slots	353-471M-E2	353-472M-E2	353-474M-E2	353-477M-E2	353-478M-E2	353-479M-E2
354-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	354-471M-E2	354-472M-E2	354-474M-E2	354-477M-E2	354-478M-E2	354-479M-E2
355-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	355-471M-E2	355-472M-E2	355-474M-E2	355-477M-E2	355-478M-E2	355-479M-E2
SYM 355-		Cover plate 2 buttons slots + 2 buttons slots + 1 button slot	SYM355- 471M-E2	SYM355- 472M-E2	SYM355- 474M-E2	SYM355- 477M-E2	SYM355- 478M-E2	SYM355- 479M-E2
356-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	356-471M-E2	356-472M-E2	356-474M-E2	356-477M-E2	356-478M-E2	356-479M-E2
360-		Cover plate 3 sockets 2P+E	360-471M-E2	360-472M-E2	360-474M-E2	360-477M-E2	360-478M-E2	360-479M-E2
361-		Cover plate 1 button slot + 2 sockets 2P+E	361-471M-E2	361-472M-E2	361-474M-E2	361-477M-E2	361-478M-E2	361-479M-E2
362-		Cover plate 2 buttons slots + 2 sockets 2P+E	362-471M-E2	362-472M-E2	362-474M-E2	362-477M-E2	362-478M-E2	362-479M-E2
363-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	363-471M-E2	363-472M-E2	363-474M-E2	363-477M-E2	363-478M-E2	363-479M-E2
387-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	387-471M-E2	387-472M-E2	387-474M-E2	387-477M-E2	387-478M-E2	387-479M-E2
364-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	364-471M-E2	364-472M-E2	364-474M-E2	364-477M-E2	364-478M-E2	364-479M-E2
365-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	365-471M-E2	365-472M-E2	365-474M-E2	365-477M-E2	365-478M-E2	365-479M-E2
376-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	376-471M-E2	376-472M-E2	376-474M-E2	376-477M-E2	376-478M-E2	376-479M-E2
366-		Cover plate 1 button slot + 1 button slot + 1 socket 2P+E	366-471M-E2	366-472M-E2	366-474M-E2	366-477M-E2	366-478M-E2	366-479M-E2
367-		Cover plate 1 button slot + 2 buttons slots + 1 socket 2P+E	367-471M-E2	367-472M-E2	367-474M-E2	367-477M-E2	367-478M-E2	367-479M-E2
357-		Cover plate 1 button slot + 1 double USB charger slot + 1 socket 2P+E	357-471M-E2	357-472M-E2	357-474M-E2	357-477M-E2	357-478M-E2	357-479M-E2
358-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	358-471M-E2	358-472M-E2	358-474M-E2	358-477M-E2	358-478M-E2	358-479M-E2
351-		Cover plate 1 button slot + 1 socket 2P+E + double USB charger slot	351-471M-E2	351-472M-E2	351-474M-E2	351-477M-E2	351-478M-E2	351-479M-E2
352-		Cover plate 2 oblong slots + 1 socket 2P+E + 1 double USB charger slot	352-471M-E2	352-472M-E2	352-474M-E2	352-477M-E2	352-478M-E2	352-479M-E2
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

E.1

E.2

E.3

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

TRIPLE VERTICAL COVER PLATES - ANGLE - E2

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple vertical cover plates - Angle

Triple cover plate dimensions:
80x222x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
390-		Cover plate 1 double charger USB slot + 1 MEDIA slot + 2 MEDIA slots	390-471M-E2	390-472M-E2	390-474M-E2	390-477M-E2	390-478M-E2	390-479M-E2
391-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 button slot	391-471M-E2	391-472M-E2	391-474M-E2	391-477M-E2	391-478M-E2	391-479M-E2
392-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	392-471M-E2	392-472M-E2	392-474M-E2	392-477M-E2	392-478M-E2	392-479M-E2
383-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	383-471M-E2	383-472M-E2	383-474M-E2	383-477M-E2	383-478M-E2	383-479M-E2
388-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	388-471M-E2	388-472M-E2	388-474M-E2	388-477M-E2	388-478M-E2	388-479M-E2
384-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	384-471M-E2	384-472M-E2	384-474M-E2	384-477M-E2	384-478M-E2	384-479M-E2
385-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	385-471M-E2	385-472M-E2	385-474M-E2	385-477M-E2	385-478M-E2	385-479M-E2
368-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	368-471M-E2	368-472M-E2	368-474M-E2	368-477M-E2	368-478M-E2	368-479M-E2
386-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 MEDIA slots	386-471M-E2	386-472M-E2	386-474M-E2	386-477M-E2	386-478M-E2	386-479M-E2
370-		Cover plate 3 MEDIA slots	370-471M-E2	370-472M-E2	370-474M-E2	370-477M-E2	370-478M-E2	370-479M-E2
371-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	371-471M-E2	371-472M-E2	371-474M-E2	371-477M-E2	371-478M-E2	371-479M-E2
372-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	372-471M-E2	372-472M-E2	372-474M-E2	372-477M-E2	372-478M-E2	372-479M-E2
373-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	373-471M-E2	373-472M-E2	373-474M-E2	373-477M-E2	373-478M-E2	373-479M-E2
374-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	374-471M-E2	374-472M-E2	374-474M-E2	374-477M-E2	374-478M-E2	374-479M-E2
375-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	375-471M-E2	375-472M-E2	375-474M-E2	375-477M-E2	375-478M-E2	375-479M-E2
378-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	378-471M-E2	378-472M-E2	378-474M-E2	378-477M-E2	378-478M-E2	378-479M-E2
380-		Cover plate 2 MEDIA slots + 1 double USB charger slot	380-471M-E2	380-472M-E2	380-474M-E2	380-477M-E2	380-478M-E2	380-479M-E2
381-		Cover plate 1 double charger USB slot + 2 MEDIA slots	381-471M-E2	381-472M-E2	381-474M-E2	381-477M-E2	381-478M-E2	381-479M-E2
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €



E.1

E.2

E.3

▪ Empreintes collection – Satin nickel – 1 button

EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

POINT



- Empreintes Collection – Point Series – Old bronze – 1 button

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

POINT

SINGLE COVER PLATES - POINT - E4

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Single cover plates - Point

Single cover plate dimensions:
80x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
131-		Cover plate 1 button slot for 230V mechanism	131-471M-E4	131-472M-E4	131-474M-E4	131-477M-E4	131-478M-E4	131-479M-E4
132-		Cover plate 2 buttons slots for 230V mechanism	132-471M-E4	132-472M-E4	132-474M-E4	132-477M-E4	132-478M-E4	132-479M-E4
RETAIL PRICE EX TAX			108,80 €	108,80 €	121,80 €	121,80 €	119,70 €	119,70 €
190-		Cover plate socket 2P+E	190-471M-E4	190-472M-E4	190-474M-E4	190-477M-E4	190-478M-E4	190-479M-E4
190-K		Cover plate schuko socket	190-471M-E4K	190-472M-E4K	190-474M-E4K	190-477M-E4K	190-478M-E4K	190-479M-E4K
RETAIL PRICE EX TAX			110,20 €	110,20 €	123,90 €	123,90 €	122,80 €	122,80 €
189-		Cover plate double USB charger slot	189-471M-E4	189-472M-E4	189-474M-E4	189-477M-E4	189-478M-E4	189-479M-E4
200-		Cover plate power delivery USB C slot	200-471M-E4	200-472M-E4	200-474M-E4	200-477M-E4	200-478M-E4	200-479M-E4
192-		Cover plate 1 MEDIA slot	192-471M-E4	192-472M-E4	192-474M-E4	192-477M-E4	192-478M-E4	192-479M-E4
193-		Cover plate 2 MEDIA slots	193-471M-E4	193-472M-E4	193-474M-E4	193-477M-E4	193-478M-E4	193-479M-E4
210-		Cover plate 1 TV slot + 1 RJ45 slot	210-471M-E4	210-472M-E4	210-474M-E4	210-477M-E4	210-478M-E4	210-479M-E4
194-		Cover plate 1 TV slot	194-471M-E4	194-472M-E4	194-474M-E4	194-477M-E4	194-478M-E4	194-479M-E4
196-		Cover plate TV/FM/SAT slots	196-471M-E4	196-472M-E4	196-474M-E4	196-477M-E4	196-478M-E4	196-479M-E4
198-		Cover plate for shutter	198-471M-E4	198-472M-E4	198-474M-E4	198-477M-E4	198-478M-E4	198-479M-E4
RETAIL PRICE EX TAX			114,40 €	114,40 €	125,90 €	125,90 €	124,80 €	124,80 €
187-		Cover plate thermostat + button	187-471M-E4	187-472M-E4	187-474M-E4	187-477M-E4	187-478M-E4	187-479M-E4
RETAIL PRICE EX TAX			170,40 €	170,40 €	181,90 €	181,90 €	177,60 €	177,60 €
191-		Cover plate rotary dimmer slot	191-471M-E4	191-472M-E4	191-474M-E4	191-477M-E4	191-478M-E4	191-479M-E4
RETAIL PRICE EX TAX			144,50 €	144,50 €	160,30 €	160,30 €	152,20 €	152,20 €
190-CL		Cover plate 2P+E socket with flap	190-471M-E4CL	190-472M-E4CL	190-474M-E4CL	190-477M-E4CL	190-478M-E4CL	190-479M-E4CL
190-CLK		Cover plate Schuko socket with flap	190-471M-E4CLK	190-472M-E4CLK	190-474M-E4CLK	190-477M-E4CLK	190-478M-E4CLK	190-479M-E4CLK
RETAIL PRICE EX TAX			220,40 €	220,40 €	247,80 €	247,80 €	245,60 €	245,60 €
190-S		Cover plate 1 swiss socket	190-471M-E4S	190-472M-E4S	190-474M-E4S	190-474M-E4S	190-478M-E4S	190-479M-E4S
190-DS		Cover plate 1 double swiss socket	190-471M-E4DS	190-472M-E4DS	190-474M-E4DS	190-474M-E4DS	190-478M-E4DS	190-479M-E4DS
190-I		Cover plate 1 bipasso socket	190-471M-E4I	190-472M-E4I	190-474M-E4I	190-474M-E4I	190-478M-E4I	190-479M-E4I
199-		Cover plate for 45x45 module	199-471M-E4	199-472M-E4	199-474M-E4	199-477M-E4	199-478M-E4	199-479M-E4
RETAIL PRICE EX TAX			110,20 €	110,20 €	123,90 €	123,90 €	122,80 €	122,80 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

POINT

DOUBLE HORIZONTAL COVER PLATES - POINT - E4

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Point

Double cover plate dimensions:
151x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
		Recommended button color	471	472	474	477	478	479
		Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass	
172-		Cover plate 2 buttons slots	172-471M-E4	172-472M-E4	172-474M-E4	172-477M-E4	172-478M-E4	172-479M-E4
177-		Cover plate 1 button + 2 buttons slots	177-471M-E4	177-472M-E4	177-474M-E4	177-477M-E4	177-478M-E4	177-479M-E4
SYM 177-		Cover plate 2 buttons + 1 button slots	SYM 177-471M-E4	SYM 177-472M-E4	SYM 177-474M-E4	SYM 177-477M-E4	SYM 177-478M-E4	SYM 177-479M-E4
174-		Cover plate 4 buttons slots	174-471M-E4	174-472M-E4	174-474M-E4	174-477M-E4	174-478M-E4	174-479M-E4
229-		Cover plate double USB charger slot + 2 buttons slots	229-471M-E4	229-472M-E4	229-474M-E4	229-477M-E4	229-478M-E4	229-479M-E4
236-		Cover plate 2 buttons slots + double USB charger slot	236-471M-E4	236-472M-E4	236-474M-E4	236-477M-E4	236-478M-E4	236-479M-E4
255-		Cover plate 1 TV slot + 1 double USB charger slot	255-471M-E4	255-472M-E4	255-474M-E4	255-477M-E4	255-478M-E4	255-479M-E4
256-		Cover plate 1 double USB charger slot + 1 MEDIA slot	256-471M-E4	256-472M-E4	256-474M-E4	256-477M-E4	256-478M-E4	256-479M-E4
257-		Cover plate 1 double USB charger slot + 1 TV slot	257-471M-E4	257-472M-E4	257-474M-E4	257-477M-E4	257-478M-E4	257-479M-E4
258-		Cover plate double USB charger slot + TV/FM/SAT slots	258-471M-E4	258-472M-E4	258-474M-E4	258-477M-E4	258-478M-E4	258-479M-E4
259-		Cover plate socket 2P+E + 1 double USB charger slot	259-471M-E4	259-472M-E4	259-474M-E4	259-477M-E4	259-478M-E4	259-479M-E4
260-		Cover plate double socket 2P+E	260-471M-E4	260-472M-E4	260-474M-E4	260-477M-E4	260-478M-E4	260-479M-E4
261-		Cover plate 1 button slot + 1 socket 2P+E	261-471M-E4	261-472M-E4	261-474M-E4	261-477M-E4	261-478M-E4	261-479M-E4
262-		Cover plate 2 buttons slots + 1 socket 2P+E	262-471M-E4	262-472M-E4	262-474M-E4	262-477M-E4	262-478M-E4	262-479M-E4
263-		Cover plate socket 2P+E + 1 MEDIA slot	263-471M-E4	263-472M-E4	263-474M-E4	263-477M-E4	263-478M-E4	263-479M-E4
264-		Cover plate 1 socket 2P+E + 2 MEDIA slots	264-471M-E4	264-472M-E4	264-474M-E4	264-477M-E4	264-478M-E4	264-479M-E4
265-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	265-471M-E4	265-472M-E4	265-474M-E4	265-477M-E4	265-478M-E4	265-479M-E4
266-		Cover plate 1 MEDIA slot + 1 MEDIA slot	266-471M-E4	266-472M-E4	266-474M-E4	266-477M-E4	266-478M-E4	266-479M-E4
267-		Cover plate 1 MEDIA slot + 2 MEDIA slots	267-471M-E4	267-472M-E4	267-474M-E4	267-477M-E4	267-478M-E4	267-479M-E4
268-		Cover plate 2 MEDIA slots + 2 MEDIA slots	268-471M-E4	268-472M-E4	268-474M-E4	268-477M-E4	268-478M-E4	268-479M-E4
269-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	269-471M-E4	269-472M-E4	269-474M-E4	269-477M-E4	269-478M-E4	269-479M-E4
270-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	270-471M-E4	270-472M-E4	270-474M-E4	270-477M-E4	270-478M-E4	270-479M-E4
271-		Cover plate 1 MEDIA slot + 1 TV slot	271-471M-E4	271-472M-E4	271-474M-E4	271-477M-E4	271-478M-E4	271-479M-E4
235-		Cover plate 1 MEDIA slot + 1 cable outlet slot	235-471M-E4	235-472M-E4	235-474M-E4	235-477M-E4	235-478M-E4	235-479M-E4
272-		Cover plate 1 socket 2P+E + 1 cable outlet slot	272-471M-E4	272-472M-E4	272-474M-E4	272-477M-E4	272-478M-E4	272-479M-E4
SYM 272-		Cover plate 1 cable outlet slot + 1 socket 2P+E	SYM 272-471M-E4	SYM 272-472M-E4	SYM 272-474M-E4	SYM 272-477M-E4	SYM 272-478M-E4	SYM 272-479M-E4
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

POINT

DOUBLE HORIZONTAL COVER PLATES - POINT - E4

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Point


Double cover plate dimensions:
151x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
273-		Cover plate 1 TV slot + 1 MEDIA slot	273-471M-E4	273-472M-E4	273-474M-E4	273-477M-E4	273-478M-E4	273-479M-E4
274-		Cover plate TV/FM/SAT slot + 1 MEDIA slot	274-471M-E4	274-472M-E4	274-474M-E4	274-477M-E4	274-478M-E4	274-479M-E4
275-		Cover plate 1 button slot + double USB charger slot	275-471M-E4	275-472M-E4	275-474M-E4	275-477M-E4	275-478M-E4	275-479M-E4
276-		Cover plate 1 MEDIA slot + 1 socket 2P+E	276-471M-E4	276-472M-E4	276-474M-E4	276-477M-E4	276-478M-E4	276-479M-E4
279-		Cover plate 1 socket 2P+E + 1 TV slot	279-471M-E4	279-472M-E4	279-474M-E4	279-477M-E4	279-478M-E4	279-479M-E4
298-		Cover plate 1 MEDIA slot + 1 double USB charger slot	298-471M-E4	298-472M-E4	298-474M-E4	298-477M-E4	298-478M-E4	298-479M-E4
295-		Cover plate 1 double USB charger slot + 1 socket 2P+E	295-471M-E4	295-472M-E4	295-474M-E4	295-477M-E4	295-478M-E4	295-479M-E4
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €
260-CL		Cover plate double socket 2P+E with flap	260-471M-E4CL	260-472M-E4CL	260-474M-E4CL	260-477M-E4CL	260-478M-E4CL	260-479M-E4CL
260-CLK		Cover plate double schuko socket with flap	260-471M-E4CLK	260-472M-E4CLK	260-474M-E4CLK	260-477M-E4CLK	260-478M-E4CLK	260-479M-E4CLK
RETAIL PRICE EX TAX			394,40 €	394,40 €	456,80 €	456,80 €	451,40 €	451,40 €

E.1

E.2

E.3



EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

POINT

DOUBLE VERTICAL COVER PLATES - POINT - E4

A complete switch consists of a cover plate and single mechanisms for the functions required.

Double vertical cover plates - Point

Double cover plate dimensions:
80x151x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
		Recommended button color	471	472	474	477	478	479
		Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass	
152-		Cover plate 2 buttons slots	152-471M-E4	152-472M-E4	152-474M-E4	152-477M-E4	152-478M-E4	152-479M-E4
155-		Cover plate 1 button + 2 buttons slots	155-471M-E4	155-472M-E4	155-474M-E4	155-477M-E4	155-478M-E4	155-479M-E4
SYM 155-		Cover plate 2 buttons + 1 button slots	SYM155-471M-E4	SYM155-472M-E4	SYM155-474M-E4	SYM155-477M-E4	SYM155-478M-E4	SYM155-479M-E4
154-		Cover plate 4 buttons slots	154-471M-E4	154-472M-E4	154-474M-E4	154-477M-E4	154-478M-E4	154-479M-E4
280-		Cover plate double socket 2P+E	280-471M-E4	280-472M-E4	280-474M-E4	280-477M-E4	280-478M-E4	280-479M-E4
281-		Cover plate 1 button slot + 1 socket 2P+E	281-471M-E4	281-472M-E4	281-474M-E4	281-477M-E4	281-478M-E4	281-479M-E4
282-		Cover plate 2 buttons slots + 1 socket 2P+E	282-471M-E4	282-472M-E4	282-474M-E4	282-477M-E4	282-478M-E4	282-479M-E4
293-		Cover plate 1 button slot + double USB charger slot	293-471M-E4	293-472M-E4	293-474M-E4	293-477M-E4	293-478M-E4	293-479M-E4
SYM 293-		Cover plate 1 double USB charger slot + 1 button slot	SYM293-471M-E4	SYM293-472M-E4	SYM293-474M-E4	SYM293-477M-E4	SYM293-478M-E4	SYM293-479M-E4
283-		Cover plate socket 2P+E + 1 MEDIA slot	283-471M-E4	283-472M-E4	283-474M-E4	283-477M-E4	283-478M-E4	283-479M-E4
284-		Cover plate 1 socket 2P+E + 2 MEDIA slots	284-471M-E4	284-472M-E4	284-474M-E4	284-477M-E4	284-478M-E4	284-479M-E4
285-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	285-471M-E4	285-472M-E4	285-474M-E4	285-477M-E4	285-478M-E4	285-479M-E4
286-		Cover plate 1 MEDIA slot + 1 MEDIA slot	286-471M-E4	286-472M-E4	286-474M-E4	286-477M-E4	286-478M-E4	286-479M-E4
287-		Cover plate 1 MEDIA slot + 2 MEDIA slots	287-471M-E4	287-472M-E4	287-474M-E4	287-477M-E4	287-478M-E4	287-479M-E4
288-		Cover plate 2 MEDIA slots + 2 MEDIA slots	288-471M-E4	288-472M-E4	288-474M-E4	288-477M-E4	288-478M-E4	288-479M-E4
289-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	289-471M-E4	289-472M-E4	289-474M-E4	289-477M-E4	289-478M-E4	289-479M-E4
290-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	290-471M-E4	290-472M-E4	290-474M-E4	290-477M-E4	290-478M-E4	290-479M-E4
292-		Cover plate 2 buttons slots + 1 MEDIA slot	292-471M-E4	292-472M-E4	292-474M-E4	292-477M-E4	292-478M-E4	292-479M-E4
RETAIL PRICE EX TAX			174,00 €	174,00 €	209,00 €	209,00 €	205,80 €	205,80 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

POINT

TRIPLE HORIZONTAL COVER PLATES - POINT - E4

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple horizontal cover plates - Point

Triple cover plate dimensions:
222x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
303-		Cover plate 3 buttons slots	303-471M-E4	303-472M-E4	303-474M-E4	303-477M-E4	303-478M-E4	303-479M-E4
304-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	304-471M-E4	304-472M-E4	304-474M-E4	304-477M-E4	304-478M-E4	304-479M-E4
305-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	305-471M-E4	305-472M-E4	305-474M-E4	305-477M-E4	305-478M-E4	305-479M-E4
306-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	306-471M-E4	306-472M-E4	306-474M-E4	306-477M-E4	306-478M-E4	306-479M-E4
311-		Cover plate 1 button slot + 2 sockets 2P+E	311-471M-E4	311-472M-E4	311-474M-E4	311-477M-E4	311-478M-E4	311-479M-E4
SYM 311-		Cover plate 2 sockets 2P+E + 1 button slot	SYM311-471M-E4	SYM311-472M-E4	SYM311-474M-E4	SYM311-477M-E4	SYM311-478M-E4	SYM311-479M-E4
312-		Cover plate 2 buttons slots + 2 sockets 2P+E	312-471M-E4	312-472M-E4	312-474M-E4	312-477M-E4	312-478M-E4	312-479M-E4
316-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	316-471M-E4	316-472M-E4	316-474M-E4	316-477M-E4	316-478M-E4	316-479M-E4
341-		Cover plate 2 buttons slots + 1 socket 2P+E + 1 double USB charger slot	341-471M-E4	341-472M-E4	341-474M-E4	341-477M-E4	341-478M-E4	341-479M-E4
342-		Cover plate 1 socket 2P+E + 2 buttons slots + 1 button slot	342-471M-E4	342-472M-E4	342-474M-E4	342-477M-E4	342-478M-E4	342-479M-E4
343-		Cover plate 1 double USB charger slot + 1 socket 2P+E + 1 button slot	343-471M-E4	343-472M-E4	343-474M-E4	343-477M-E4	343-478M-E4	343-479M-E4
345-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	345-471M-E4	345-472M-E4	345-474M-E4	345-477M-E4	345-478M-E4	345-479M-E4
346-		Cover plate 1 button slot + 1 socket 2P+E + 1 double USB charger slot	346-471M-E4	346-472M-E4	346-474M-E4	346-477M-E4	346-478M-E4	346-479M-E4
308-		Cover plate socket 2P+E + 1 double USB charger slot + 1 button slot	308-471M-E4	308-472M-E4	308-474M-E4	308-477M-E4	308-478M-E4	308-479M-E4
309-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	309-471M-E4	309-472M-E4	309-474M-E4	309-477M-E4	309-478M-E4	309-479M-E4
310-		Cover plate 3 sockets 2P+E	310-471M-E4	310-472M-E4	310-474M-E4	310-477M-E4	310-478M-E4	310-479M-E4
313-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	313-471M-E4	313-472M-E4	313-474M-E4	313-477M-E4	313-478M-E4	313-479M-E4
337-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	337-471M-E4	337-472M-E4	337-474M-E4	337-477M-E4	337-478M-E4	337-479M-E4
314-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	314-471M-E4	314-472M-E4	314-474M-E4	314-477M-E4	314-478M-E4	314-479M-E4
315-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	315-471M-E4	315-472M-E4	315-474M-E4	315-477M-E4	315-478M-E4	315-479M-E4
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

POINT

TRIPLE HORIZONTAL COVER PLATES - POINT - E4

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple horizontal cover plates - Point

Triple cover plate dimensions:
222x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
344-		Cover plate 2 sockets 2P+E + 1 cable outlet slot	344-471M-E4	344-472M-E4	344-474M-E4	344-477M-E4	344-478M-E4	344-479M-E4
319-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 TV slot	319-471M-E4	319-472M-E4	319-474M-E4	319-477M-E4	319-478M-E4	319-479M-E4
330-		Cover plate 2 MEDIA slots + 1 double USB charger slot	330-471M-E4	330-472M-E4	330-474M-E4	330-477M-E4	330-478M-E4	330-479M-E4
331-		Cover plate 1 double charger USB slot + 2 MEDIA slots	331-471M-E4	331-472M-E4	331-474M-E4	331-477M-E4	331-478M-E4	331-479M-E4
332-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 TV slot	332-471M-E4	332-472M-E4	332-474M-E4	332-477M-E4	332-478M-E4	332-479M-E4
333-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	333-471M-E4	333-472M-E4	333-474M-E4	333-477M-E4	333-478M-E4	333-479M-E4
334-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	334-471M-E4	334-472M-E4	334-474M-E4	334-477M-E4	334-478M-E4	334-479M-E4
335-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	335-471M-E4	335-472M-E4	335-474M-E4	335-477M-E4	335-478M-E4	335-479M-E4
338-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	338-471M-E4	338-472M-E4	338-474M-E4	338-477M-E4	338-478M-E4	338-479M-E4
320-		Cover plate 3 MEDIA slots	320-471M-E4	320-472M-E4	320-474M-E4	320-477M-E4	320-478M-E4	320-479M-E4
321-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	321-471M-E4	321-472M-E4	321-474M-E4	321-477M-E4	321-478M-E4	321-479M-E4
322-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	322-471M-E4	322-472M-E4	322-474M-E4	322-477M-E4	322-478M-E4	322-479M-E4
323-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	323-471M-E4	323-472M-E4	323-474M-E4	323-477M-E4	323-478M-E4	323-479M-E4
324-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	324-471M-E4	324-472M-E4	324-474M-E4	324-477M-E4	324-478M-E4	324-479M-E4
325-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	325-471M-E4	325-472M-E4	325-474M-E4	325-477M-E4	325-478M-E4	325-479M-E4
326-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	326-471M-E4	326-472M-E4	326-474M-E4	326-477M-E4	326-478M-E4	326-479M-E4
327-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	327-471M-E4	327-472M-E4	327-474M-E4	327-477M-E4	327-478M-E4	327-479M-E4
328-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	328-471M-E4	328-472M-E4	328-474M-E4	328-477M-E4	328-478M-E4	328-479M-E4
329-		Cover plate 2 sockets 2P+E + 1 TV slot	329-471M-E4	329-472M-E4	329-474M-E4	329-477M-E4	329-478M-E4	329-479M-E4
301-		Cover plate 1 MEDIA slot + 2 sockets 2P+E	301-471M-E4	301-472M-E4	301-474M-E4	301-477M-E4	301-478M-E4	301-479M-E4
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

POINT

TRIPLE VERTICAL COVER PLATES - POINT - E4

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple vertical cover plates - Point

Triple cover plate dimensions:
80x222x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
353-		Cover plate 3 buttons slots	353-471M-E4	353-472M-E4	353-474M-E4	353-477M-E4	353-478M-E4	353-479M-E4
354-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	354-471M-E4	354-472M-E4	354-474M-E4	354-477M-E4	354-478M-E4	354-479M-E4
355-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	355-471M-E4	355-472M-E4	355-474M-E4	355-477M-E4	355-478M-E4	355-479M-E4
SYM 355-		Cover plate 2 buttons slots + 2 buttons slots + 1 button slot	SYM355-471M-E4	SYM355-472M-E4	SYM355-474M-E4	SYM355-477M-E4	SYM355-478M-E4	SYM355-479M-E4
356-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	356-471M-E4	356-472M-E4	356-474M-E4	356-477M-E4	356-478M-E4	356-479M-E4
360-		Cover plate 3 sockets 2P+E	360-471M-E4	360-472M-E4	360-474M-E4	360-477M-E4	360-478M-E4	360-479M-E4
361-		Cover plate 1 button slot + 2 sockets 2P+E	361-471M-E4	361-472M-E4	361-474M-E4	361-477M-E4	361-478M-E4	361-479M-E4
362-		Cover plate 2 buttons slots + 2 sockets 2P+E	362-471M-E4	362-472M-E4	362-474M-E4	362-477M-E4	362-478M-E4	362-479M-E4
363-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	363-471M-E4	363-472M-E4	363-474M-E4	363-477M-E4	363-478M-E4	363-479M-E4
387-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	387-471M-E4	387-472M-E4	387-474M-E4	387-477M-E4	387-478M-E4	387-479M-E4
364-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	364-471M-E4	364-472M-E4	364-474M-E4	364-477M-E4	364-478M-E4	364-479M-E4
365-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	365-471M-E4	365-472M-E4	365-474M-E4	365-477M-E4	365-478M-E4	365-479M-E4
376-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	376-471M-E4	376-472M-E4	376-474M-E4	376-477M-E4	376-478M-E4	376-479M-E4
366-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	366-471M-E4	366-472M-E4	366-474M-E4	366-477M-E4	366-478M-E4	366-479M-E4
367-		Cover plate 1 button slot + 2 buttons slots + 1 socket 2P+E	367-471M-E4	367-472M-E4	367-474M-E4	367-477M-E4	367-478M-E4	367-479M-E4
357-		Cover plate 1 button slot + 1 double USB charger slot + 1 socket 2P+E	357-471M-E4	357-472M-E4	357-474M-E4	357-477M-E4	357-478M-E4	357-479M-E4
358-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	358-471M-E4	358-472M-E4	358-474M-E4	358-477M-E4	358-478M-E4	358-479M-E4
351-		Cover plate 1 button slot + 1 socket 2P+E + double USB charger slot	351-471M-E4	351-472M-E4	351-474M-E4	351-477M-E4	351-478M-E4	351-479M-E4
352-		Cover plate 2 oblong slots + 1 socket 2P+E + 1 double USB charger slot	352-471M-E4	352-472M-E4	352-474M-E4	352-477M-E4	352-478M-E4	352-479M-E4
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

POINT

TRIPLE VERTICAL COVER PLATES - POINT - E4


A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple vertical cover plates - Point

Triple cover plate dimensions:
80x222x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
390-		Cover plate 1 double charger USB slot + 1 MEDIA slot + 2 MEDIA slots	390-471M-E4	390-472M-E4	390-474M-E4	390-477M-E4	390-478M-E4	390-479M-E4
391-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 button slot	391-471M-E4	391-472M-E4	391-474M-E4	391-477M-E4	391-478M-E4	391-479M-E4
392-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	392-471M-E4	392-472M-E4	392-474M-E4	392-477M-E4	392-478M-E4	392-479M-E4
383-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	383-471M-E4	383-472M-E4	383-474M-E4	383-477M-E4	383-478M-E4	383-479M-E4
388-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	388-471M-E4	388-472M-E4	388-474M-E4	388-477M-E4	388-478M-E4	388-479M-E4
384-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	384-471M-E4	384-472M-E4	384-474M-E4	384-477M-E4	384-478M-E4	384-479M-E4
385-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	385-471M-E4	385-472M-E4	385-474M-E4	385-477M-E4	385-478M-E4	385-479M-E4
368-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	368-471M-E4	368-472M-E4	368-474M-E4	368-477M-E4	368-478M-E4	368-479M-E4
386-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 MEDIA slots	386-471M-E4	386-472M-E4	386-474M-E4	386-477M-E4	386-478M-E4	386-479M-E4
370-		Cover plate 3 MEDIA slots	370-471M-E4	370-472M-E4	370-474M-E4	370-477M-E4	370-478M-E4	370-479M-E4
371-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	371-471M-E4	371-472M-E4	371-474M-E4	371-477M-E4	371-478M-E4	371-479M-E4
372-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	372-471M-E4	372-472M-E4	372-474M-E4	372-477M-E4	372-478M-E4	372-479M-E4
373-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	373-471M-E4	373-472M-E4	373-474M-E4	373-477M-E4	373-478M-E4	373-479M-E4
374-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	374-471M-E4	374-472M-E4	374-474M-E4	374-477M-E4	374-478M-E4	374-479M-E4
375-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	375-471M-E4	375-472M-E4	375-474M-E4	375-477M-E4	375-478M-E4	375-479M-E4
378-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	378-471M-E4	378-472M-E4	378-474M-E4	378-477M-E4	378-478M-E4	378-479M-E4
380-		Cover plate 2 MEDIA slots + 1 double USB charger slot	380-471M-E4	380-472M-E4	380-474M-E4	380-477M-E4	380-478M-E4	380-479M-E4
381-		Cover plate 1 double charger USB slot + 2 MEDIA slots	381-471M-E4	381-472M-E4	381-474M-E4	381-477M-E4	381-478M-E4	381-479M-E4
RETAIL PRICE EX TAX			249,00 €	249,00 €	322,00 €	322,00 €	296,90 €	296,90 €

POINT



E.1

E.2

E.3

- Empreintes collection – Point series – Satin nickel – 1 button

LIGNE



- Empreintes collection – Ligne series – Gun metal – 1 button


EMPREINTES COLLECTION ▪ COVER PLATES WITH FLAT BUTTONS

LIGNE

SINGLE COVER PLATES - LIGNE - E5

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Single cover plates - Ligne

Single cover plate dimensions:
80x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
		Recommended button color	Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
131-		Cover plate 1 button slot for 230V mechanism	131-471M-E5	131-472M-E5	131-474M-E5	131-477M-E5	131-478M-E5	131-479M-E5
132-		Cover plate 2 buttons slots for 230V mechanism	132-471M-E5	132-472M-E5	132-474M-E5	132-477M-E5	132-478M-E5	132-479M-E5
RETAIL PRICE EX TAX			115,00 €	115,00 €	127,50 €	127,50 €	125,50 €	125,50 €
190-		Cover plate socket 2P+E	190-471M-E5	190-472M-E5	190-474M-E5	190-477M-E5	190-478M-E5	190-479M-E5
190-K		Cover plate schuko socket	190-471M-E5K	190-472M-E5K	190-474M-E5K	190-477M-E5K	190-478M-E5K	190-479M-E5K
RETAIL PRICE EX TAX			116,80 €	116,80 €	129,60 €	129,60 €	128,50 €	128,50 €
189-		Cover plate double USB charger slot	189-471M-E5	189-472M-E5	189-474M-E5	189-477M-E5	189-478M-E5	189-479M-E5
200-		Cover plate power delivery USB C slot	200-471M-E5	200-472M-E5	200-474M-E5	200-477M-E5	200-478M-E5	200-479M-E5
192-		Cover plate 1 MEDIA slot	192-471M-E5	192-472M-E5	192-474M-E5	192-477M-E5	192-478M-E5	192-479M-E5
193-		Cover plate 2 MEDIA slots	193-471M-E5	193-472M-E5	193-474M-E5	193-477M-E5	193-478M-E5	193-479M-E5
210-		Cover plate 1 TV slot + 1 RJ45 slot	210-471M-E5	210-472M-E5	210-474M-E5	210-477M-E5	210-478M-E5	210-479M-E5
194-		Cover plate 1 TV slot	194-471M-E5	194-472M-E5	194-474M-E5	194-477M-E5	194-478M-E5	194-479M-E5
196-		Cover plate TV/FM/SAT slots	196-471M-E5	196-472M-E5	196-474M-E5	196-477M-E5	196-478M-E5	196-479M-E5
198-		Cover plate for shutter	198-471M-E5	198-472M-E5	198-474M-E5	198-477M-E5	198-478M-E5	198-479M-E5
RETAIL PRICE EX TAX			119,50 €	119,50 €	131,30 €	131,30 €	130,10 €	130,10 €
191-		Cover plate rotary dimmer slot	191-471M-E5	191-472M-E5	191-474M-E5	191-477M-E5	191-478M-E5	191-479M-E5
RETAIL PRICE EX TAX			153,90 €	153,90 €	165,70 €	165,70 €	164,50 €	164,50 €
190-S		Cover plate 1 swiss socket	190-471M-E5S	190-472M-E5S	190-474M-E5S	190-474M-E5S	190-478M-E5S	190-479M-E5S
190-DS		Cover plate 1 double swiss socket	190-471M-E5DS	190-472M-E5DS	190-474M-E5DS	190-474M-E5DS	190-478M-E5DS	190-479M-E5DS
190-I		Cover plate 1 bipasso socket	190-471M-E5I	190-472M-E5I	190-474M-E5I	190-474M-E5I	190-478M-E5I	190-479M-E5I
199-		Cover plate for 45x45 module	199-471M-E5	199-472M-E5	199-474M-E5	199-477M-E5	199-478M-E5	199-479M-E5
RETAIL PRICE EX TAX			116,80 €	116,80 €	129,60 €	129,60 €	128,50 €	128,50 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

LIGNE

DOUBLE HORIZONTAL COVER PLATES - LIGNE - E5

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Ligne

Double cover plate dimensions:
151x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
172-		Cover plate 2 buttons slots	172-471M-E5	172-472M-E5	172-474M-E5	172-477M-E5	172-478M-E5	172-479M-E5
177-		Cover plate 1 button + 2 buttons slots	177-471M-E5	177-472M-E5	177-474M-E5	177-477M-E5	177-478M-E5	177-479M-E5
SYM 177-		Cover plate 2 buttons + 1 button slots	SYM177-471M-E5	SYM177-472M-E5	SYM177-474M-E5	SYM177-477M-E5	SYM177-478M-E5	SYM177-479M-E5
174-		Cover plate 4 buttons slots	174-471M-E5	174-472M-E5	174-474M-E5	174-477M-E5	174-478M-E5	174-479M-E5
229-		Cover plate double USB charger slot + 2 buttons slots	229-471M-E5	229-472M-E5	229-474M-E5	229-477M-E5	229-478M-E5	229-479M-E5
236-		Cover plate 2 buttons slots + double USB charger slot	236-471M-E5	236-472M-E5	236-474M-E5	236-477M-E5	236-478M-E5	236-479M-E5
255-		Cover plate 1 TV slot + 1 double USB charger slot	255-471M-E5	255-472M-E5	255-474M-E5	255-477M-E5	255-478M-E5	255-479M-E5
256-		Cover plate 1 double USB charger slot + 1 MEDIA slot	256-471M-E5	256-472M-E5	256-474M-E5	256-477M-E5	256-478M-E5	256-479M-E5
257-		Cover plate 1 double USB charger slot + 1 TV	257-471M-E5	257-472M-E5	257-474M-E5	257-477M-E5	257-478M-E5	257-479M-E5
258-		Cover plate double USB charger slot + TV/FM/SAT slots	258-471M-E5	258-472M-E5	258-474M-E5	258-477M-E5	258-478M-E5	258-479M-E5
259-		Cover plate socket 2P+E + 1 double USB charger slot	259-471M-E5	259-472M-E5	259-474M-E5	259-477M-E5	259-478M-E5	259-479M-E5
260-		Cover plate double socket 2P+E	260-471M-E5	260-472M-E5	260-474M-E5	260-477M-E5	260-478M-E5	260-479M-E5
261-		Cover plate 1 button slot + 1 socket 2P+E	261-471M-E5	261-472M-E5	261-474M-E5	261-477M-E5	261-478M-E5	261-479M-E5
262-		Cover plate 2 buttons slots + 1 socket 2P+E	262-471M-E5	262-472M-E5	262-474M-E5	262-477M-E5	262-478M-E5	262-479M-E5
263-		Cover plate socket 2P+E + 1 MEDIA slot	263-471M-E5	263-472M-E5	263-474M-E5	263-477M-E5	263-478M-E5	263-479M-E5
264-		Cover plate 1 socket 2P+E + 2 MEDIA slots	264-471M-E5	264-472M-E5	264-474M-E5	264-477M-E5	264-478M-E5	264-479M-E5
265-		Cover plate 1 socket 2P+E + TV/FM/SAT slots	265-471M-E5	265-472M-E5	265-474M-E5	265-477M-E5	265-478M-E5	265-479M-E5
266-		Cover plate 1 MEDIA slot + 1 MEDIA slot	266-471M-E5	266-472M-E5	266-474M-E5	266-477M-E5	266-478M-E5	266-479M-E5
267-		Cover plate 1 MEDIA slot + 2 MEDIA slots	267-471M-E5	267-472M-E5	267-474M-E5	267-477M-E5	267-478M-E5	267-479M-E5
268-		Cover plate 2 MEDIA slots + 2 MEDIA slots	268-471M-E5	268-472M-E5	268-474M-E5	268-477M-E5	268-478M-E5	268-479M-E5
269-		Cover plate 1 MEDIA slot + TV/FM/SAT slots	269-471M-E5	269-472M-E5	269-474M-E5	269-477M-E5	269-478M-E5	269-479M-E5
270-		Cover plate 2 MEDIA slots + TV/FM/SAT slots	270-471M-E5	270-472M-E5	270-474M-E5	270-477M-E5	270-478M-E5	270-479M-E5
271-		Cover plate 1 MEDIA slot + 1 TV slot	271-471M-E5	271-472M-E5	271-474M-E5	271-477M-E5	271-478M-E5	271-479M-E5
RETAIL PRICE EX TAX			190,00 €	190,00 €	219,50 €	219,50 €	215,00 €	215,00 €

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

LIGNE

DOUBLE HORIZONTAL COVER PLATES - LIGNE - E5

A complete switch consists of a cover plate and single mechanisms for the functions required.

Example: cover plate + mechanism



Double horizontal cover plates - Ligne


Double cover plate dimensions:
151x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
235-		Cover plate 1 MEDIA slot + 1 cable outlet slot	235-471M-E5	235-472M-E5	235-474M-E5	235-477M-E5	235-478M-E5	235-479M-E5
272-		Cover plate 1 socket 2P+E + 1 cable outlet slot	272-471M-E5	272-472M-E5	272-474M-E5	272-477M-E5	272-478M-E5	272-479M-E5
SYM 272-		Cover plate 1 cable outlet slot + 1 socket 2P+E	SYM272-471M-E5	SYM272-472M-E5	SYM272-474M-E5	SYM272-477M-E5	SYM272-478M-E5	SYM272-479M-E5
273-		Cover plate 1 TV slot + 1 MEDIA slot	273-471M-E5	273-472M-E5	273-474M-E5	273-477M-E5	273-478M-E5	273-479M-E5
274-		Cover plate TV/FM/SAT slot + 1 MEDIA slot	274-471M-E5	274-472M-E5	274-474M-E5	274-477M-E5	274-478M-E5	274-479M-E5
275-		Cover plate 1 button slot + double USB charger slot	275-471M-E5	275-472M-E5	275-474M-E5	275-477M-E5	275-478M-E5	275-479M-E5
276-		Cover plate 1 MEDIA slot + 1 socket 2P+E	276-471M-E5	276-472M-E5	276-474M-E5	276-477M-E5	276-478M-E5	276-479M-E5
279-		Cover plate 1 socket 2P+E + 1 TV slot	279-471M-E5	279-472M-E5	279-474M-E5	279-477M-E5	279-478M-E5	279-479M-E5
298-		Cover plate 1 MEDIA slot + 1 double USB charger slot	298-471M-E5	298-472M-E5	298-474M-E5	298-477M-E5	298-478M-E5	298-479M-E5
295-		Cover plate 1 double USB charger slot + 1 socket 2P+E	295-471M-E5	295-472M-E5	295-474M-E5	295-477M-E5	295-478M-E5	295-479M-E5
RETAIL PRICE EX TAX			190,00 €	190,00 €	219,50 €	219,50 €	215,00 €	215,00 €

E.1

E.2

E.3



EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

LIGNE

TRIPLE HORIZONTAL COVER PLATES - LIGNE - E5

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple horizontal cover plates - Ligne

Triple cover plate dimensions:
222x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
303-		Cover plate 3 buttons slots	303-471M-E5	303-472M-E5	303-474M-E5	303-477M-E5	303-478M-E5	303-479M-E5
304-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	304-471M-E5	304-472M-E5	304-474M-E5	304-477M-E5	304-478M-E5	304-479M-E5
305-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	305-471M-E5	305-472M-E5	305-474M-E5	305-477M-E5	305-478M-E5	305-479M-E5
306-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	306-471M-E5	306-472M-E5	306-474M-E5	306-477M-E5	306-478M-E5	306-479M-E5
311-		Cover plate 1 button slot + 2 sockets 2P+E	311-471M-E5	311-472M-E5	311-474M-E5	311-477M-E5	311-478M-E5	311-479M-E5
SYM311-		Cover plate 2 sockets 2P+E + 1 button slot	SYM311-471M-E5	SYM311-472M-E5	SYM311-474M-E5	SYM311-477M-E5	SYM311-478M-E5	SYM311-479M-E5
312-		Cover plate 2 buttons slots + 2 sockets 2P+E	312-471M-E5	312-472M-E5	312-474M-E5	312-477M-E5	312-478M-E5	312-479M-E5
316-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	316-471M-E5	316-472M-E5	316-474M-E5	316-477M-E5	316-478M-E5	316-479M-E5
341-		Cover plate 2 buttons slots + 1 socket 2P+E + 1 double USB charger slot	341-471M-E5	341-472M-E5	341-474M-E5	341-477M-E5	341-478M-E5	341-479M-E5
342-		Cover plate 1 socket 2P+E + 2 buttons slots + 1 button slot	342-471M-E5	342-472M-E5	342-474M-E5	342-477M-E5	342-478M-E5	342-479M-E5
343-		Cover plate 1 double USB charger slot + 1 socket 2P+E + 1 button slot	343-471M-E5	343-472M-E5	343-474M-E5	343-477M-E5	343-478M-E5	343-479M-E5
345-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	345-471M-E5	345-472M-E5	345-474M-E5	345-477M-E5	345-478M-E5	345-479M-E5
346-		Cover plate 1 button slot + 1 socket 2P+E + 1 double USB charger slot	346-471M-E5	346-472M-E5	346-474M-E5	346-477M-E5	346-478M-E5	346-479M-E5
308-		Cover plate socket 2P+E + 1 double USB charger slot + 1 button slot	308-471M-E5	308-472M-E5	308-474M-E5	308-477M-E5	308-478M-E5	308-479M-E5
309-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	309-471M-E5	309-472M-E5	309-474M-E5	309-477M-E5	309-478M-E5	309-479M-E5
310-		Cover plate 3 sockets 2P+E	310-471M-E5	310-472M-E5	310-474M-E5	310-477M-E5	310-478M-E5	310-479M-E5
313-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	313-471M-E5	313-472M-E5	313-474M-E5	313-477M-E5	313-478M-E5	313-479M-E5
337-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	337-471M-E5	337-472M-E5	337-474M-E5	337-477M-E5	337-478M-E5	337-479M-E5
314-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	314-471M-E5	314-472M-E5	314-474M-E5	314-477M-E5	314-478M-E5	314-479M-E5
315-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	315-471M-E5	315-472M-E5	315-474M-E5	315-477M-E5	315-478M-E5	315-479M-E5
RETAIL PRICE EX TAX			279,50 €	279,50 €	336,50 €	336,50 €	316,00 €	316,00 €

LIGNE

TRIPLE HORIZONTAL COVER PLATES - LIGNE - E5

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple horizontal cover plates - Ligne

Triple cover plate dimensions:
222x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
Recommended button color			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
303-		Cover plate 3 buttons slots	303-471M-E5	303-472M-E5	303-474M-E5	303-477M-E5	303-478M-E5	303-479M-E5
304-		Cover plate 1 button slot + 1 button slot + 2 buttons slots	304-471M-E5	304-472M-E5	304-474M-E5	304-477M-E5	304-478M-E5	304-479M-E5
305-		Cover plate 1 button slot + 2 buttons slots + 2 buttons slots	305-471M-E5	305-472M-E5	305-474M-E5	305-477M-E5	305-478M-E5	305-479M-E5
306-		Cover plate 2 buttons slots + 2 buttons slots + 2 buttons slots	306-471M-E5	306-472M-E5	306-474M-E5	306-477M-E5	306-478M-E5	306-479M-E5
311-		Cover plate 1 button slot + 2 sockets 2P+E	311-471M-E5	311-472M-E5	311-474M-E5	311-477M-E5	311-478M-E5	311-479M-E5
SYM311-		Cover plate 2 sockets 2P+E + 1 button slot	SYM311-471M-E5	SYM311-472M-E5	SYM311-474M-E5	SYM311-477M-E5	SYM311-478M-E5	SYM311-479M-E5
312-		Cover plate 2 buttons slots + 2 sockets 2P+E	312-471M-E5	312-472M-E5	312-474M-E5	312-477M-E5	312-478M-E5	312-479M-E5
316-		Cover plate 1 button slot + 1 buttons slot + 1 socket 2P+E	316-471M-E5	316-472M-E5	316-474M-E5	316-477M-E5	316-478M-E5	316-479M-E5
341-		Cover plate 2 buttons slots + 1 socket 2P+E + 1 double USB charger slot	341-471M-E5	341-472M-E5	341-474M-E5	341-477M-E5	341-478M-E5	341-479M-E5
342-		Cover plate 1 socket 2P+E + 2 buttons slots + 1 button slot	342-471M-E5	342-472M-E5	342-474M-E5	342-477M-E5	342-478M-E5	342-479M-E5
343-		Cover plate 1 double USB charger slot + 1 socket 2P+E + 1 button slot	343-471M-E5	343-472M-E5	343-474M-E5	343-477M-E5	343-478M-E5	343-479M-E5
345-		Cover plate 2 button slots + 1 double USB charger slot + 1 socket 2P+E	345-471M-E5	345-472M-E5	345-474M-E5	345-477M-E5	345-478M-E5	345-479M-E5
346-		Cover plate 1 button slot + 1 socket 2P+E + 1 double USB charger slot	346-471M-E5	346-472M-E5	346-474M-E5	346-477M-E5	346-478M-E5	346-479M-E5
308-		Cover plate socket 2P+E + 1 double USB charger slot + 1 button slot	308-471M-E5	308-472M-E5	308-474M-E5	308-477M-E5	308-478M-E5	308-479M-E5
309-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 2 buttons slots	309-471M-E5	309-472M-E5	309-474M-E5	309-477M-E5	309-478M-E5	309-479M-E5
310-		Cover plate 3 sockets 2P+E	310-471M-E5	310-472M-E5	310-474M-E5	310-477M-E5	310-478M-E5	310-479M-E5
313-		Cover plate 2 sockets 2P+E + 1 MEDIA slot	313-471M-E5	313-472M-E5	313-474M-E5	313-477M-E5	313-478M-E5	313-479M-E5
337-		Cover plate 2 sockets 2P+E + 1 double USB charger slot	337-471M-E5	337-472M-E5	337-474M-E5	337-477M-E5	337-478M-E5	337-479M-E5
314-		Cover plate 2 sockets 2P+E + 2 MEDIA slots	314-471M-E5	314-472M-E5	314-474M-E5	314-477M-E5	314-478M-E5	314-479M-E5
315-		Cover plate 2 sockets 2P+E + TV/FM/SAT slots	315-471M-E5	315-472M-E5	315-474M-E5	315-477M-E5	315-478M-E5	315-479M-E5
RETAIL PRICE EX TAX			279,50 €	279,50 €	336,50 €	336,50 €	316,00 €	316,00 €

E.1

E.2

E.3

EMPREINTES COLLECTION • COVER PLATES WITH FLAT BUTTONS

LIGNE

TRIPLE HORIZONTAL COVER PLATES - LIGNE - E5

A complete switch consists of a cover plate and single mechanisms for the functions required.

Triple horizontal cover plates - Ligne

Triple cover plate dimensions:

222x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
344-		Cover plate 2 sockets 2P+E + 1 cable outlet slot	344-471M-E5	344-472M-E5	344-474M-E5	344-477M-E5	344-478M-E5	344-479M-E5
319-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 TV slot	319-471M-E5	319-472M-E5	319-474M-E5	319-477M-E5	319-478M-E5	319-479M-E5
330-		Cover plate 2 MEDIA slots + 1 double USB charger slot	330-471M-E5	330-472M-E5	330-474M-E5	330-477M-E5	330-478M-E5	330-479M-E5
331-		Cover plate 1 double charger USB slot + 2 MEDIA slots	331-471M-E5	331-472M-E5	331-474M-E5	331-477M-E5	331-478M-E5	331-479M-E5
332-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 TV slot	332-471M-E5	332-472M-E5	332-474M-E5	332-477M-E5	332-478M-E5	332-479M-E5
333-		Cover plate 1 socket 2P+E + 1 double USB charger slot + TV/FM/SAT slots	333-471M-E5	333-472M-E5	333-474M-E5	333-477M-E5	333-478M-E5	333-479M-E5
334-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 double USB charger slot	334-471M-E5	334-472M-E5	334-474M-E5	334-477M-E5	334-478M-E5	334-479M-E5
335-		Cover plate 1 socket 2P+E + 1 double USB charger slot + 1 MEDIA slot	335-471M-E5	335-472M-E5	335-474M-E5	335-477M-E5	335-478M-E5	335-479M-E5
338-		Cover plate 1 double USB charger slot + 1 MEDIA slot + TV/FM/SAT slot	338-471M-E5	338-472M-E5	338-474M-E5	338-477M-E5	338-478M-E5	338-479M-E5
320-		Cover plate 3 MEDIA slots	320-471M-E5	320-472M-E5	320-474M-E5	320-477M-E5	320-478M-E5	320-479M-E5
321-		Cover plate 1 MEDIA slot + 1 MEDIA slot + 2 MEDIA slots	321-471M-E5	321-472M-E5	321-474M-E5	321-477M-E5	321-478M-E5	321-479M-E5
322-		Cover plate 1 MEDIA slot + 2 MEDIA slots + 2 MEDIA slots	322-471M-E5	322-472M-E5	322-474M-E5	322-477M-E5	322-478M-E5	322-479M-E5
323-		Cover plate 2 MEDIA slots + 2 MEDIA slots + 2 MEDIA slots	323-471M-E5	323-472M-E5	323-474M-E5	323-477M-E5	323-478M-E5	323-479M-E5
324-		Cover plate 1 socket 2P+E + 1 MEDIA slot + TV/FM/SAT slots	324-471M-E5	324-472M-E5	324-474M-E5	324-477M-E5	324-478M-E5	324-479M-E5
325-		Cover plate 1 socket 2P+E + 2 MEDIA slots + TV/FM/SAT slots	325-471M-E5	325-472M-E5	325-474M-E5	325-477M-E5	325-478M-E5	325-479M-E5
326-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 1 MEDIA slot	326-471M-E5	326-472M-E5	326-474M-E5	326-477M-E5	326-478M-E5	326-479M-E5
327-		Cover plate 1 socket 2P+E + 1 MEDIA slot + 2 MEDIA slots	327-471M-E5	327-472M-E5	327-474M-E5	327-477M-E5	327-478M-E5	327-479M-E5
328-		Cover plate 1 MEDIA slot + 1 MEDIA slot + TV/FM/SAT slots	328-471M-E5	328-472M-E5	328-474M-E5	328-477M-E5	328-478M-E5	328-479M-E5
329-		Cover plate 2 sockets 2P+E + 1 TV slot	329-471M-E5	329-472M-E5	329-474M-E5	329-477M-E5	329-478M-E5	329-479M-E5
301-		Cover plate 1 MEDIA slot + 2 sockets 2P+E	301-471M-E5	301-472M-E5	301-474M-E5	301-477M-E5	301-478M-E5	301-479M-E5
RETAIL PRICE EX TAX			279,50 €	279,50 €	336,50 €	336,50 €	316,00 €	316,00 €

LIGNE



E.1

E.2

E.3

- Empreintes collection – Ligne series – Old bronze – 1 button

■ THE SEMI-INTEGRATED FLAT-BUTTON SOLUTION

It features a **Modelec** mechanism equipped with full-material buttons compatible with very low voltage. These mechanisms are available in two versions: with a pre-wired THEBEN input module (including the **KNX** protocol, the industry standard in home automation), or to be paired with the module of your choice.

These mechanisms are easy to install and connect to your electrical system.

A wide range of possibilities is available to you: up to **5 controls on a single mechanism (i.e., 15 functions)** and the option to add indicator lights (5V LEDs).

Full-material plates and flat buttons can be engraved.


Our flat buttons for home automation can be combined with other functions on a multi-function plate.



APPLICATIONS

ON/OFF
SWITCH


DIMMING



MANAGING OPENINGS



HOME AUTOMATION SCENARIO



EMPREINTES COLLECTION
POINT SERIES - OLD BRONZE

FEATURES


Button dimensions:
12,5x12,5 mm

Solid brass buttons
with or without **LED's**

1 to 4 flat square buttons

For non-standard requests, please contact our sales department.

 The operating voltage of the LED is 5V, a common value for a home automation input module.
For 8V supplies, the 076KIT200 protection kit is mandatory.
For higher voltages, please specify it when ordering.



E.1

E.2

E.3

▪ Empreintes collection – Plan series –
3 buttons for home automation applications

SQUARE FLAT BUTTON LOW VOLTAGE MECHANISMS

A complete switch consists of a cover plate and a single mechanism for the functions required.

Example: cover plate + mechanism



Pre-wired square flat button mechanisms.
Low voltage ≤ 48V

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass	RETAIL PRICE EX TAX
			471	472	474	477	478	479	
-668G		Mechanism 1 square flat button	076-668G471	076-668G472	076-668G474	076-668G477	076-668G478	076-668G479	36,10 €
-669G		Mechanism 2 square flat buttons	076-669G471	076-669G472	076-669G474	076-669G477	076-669G478	076-669G479	69,70 €
-670G		Mechanism 3 square flat buttons	076-670G471	076-670G472	076-670G474	076-670G477	076-670G478	076-670G479	99,40 €
-677G		Mechanism 3 square flat buttons L-shaped	076-677G471	076-677G472	076-677G474	076-677G477	076-677G478	076-677G479	99,40 €
-671G		Mechanism 4 square flat buttons	076-671G471	076-671G472	076-671G474	076-671G477	076-671G478	076-671G479	130,00 €

Pre-wired square flat button mechanisms
with LED. Low voltage ≤ 48V

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass	RETAIL PRICE EX TAX
			471	472	474	477	478	479	
-668G-L		Mechanism 1 square flat button with LED	076-668G471-L	076-668G472-L	076-668G474-L	076-668G477-L	076-668G478-L	076-668G479-L	47,30 €
-669G-L		Mechanism 2 square flat buttons with LED	076-669G471-L	076-669G472-L	076-669G474-L	076-669G477-L	076-669G478-L	076-669G479-L	93,00 €
-670G-L		Mechanism 3 square flat buttons with LED	076-670G471-L	076-670G472-L	076-670G474-L	076-670G477-L	076-670G478-L	076-670G479-L	141,70 €
-677G-L		Mechanism 3 square flat buttons L-shaped with LED	076-677G471-L	076-677G472-L	076-677G474-L	076-677G477-L	076-677G478-L	076-677G479-L	141,70 €
-671G-L		Mechanism 4 square flat buttons with LED	076-671G471-L	076-671G472-L	076-671G474-L	076-671G477-L	076-671G478-L	076-671G479-L	184,00 €

PRE-WIRED SQUARE FLAT BUTTON LOW VOLTAGE MECHANISMS

Our mechanisms are pre-wired with a THEBEN input module.



Example: cover plate + mechanism



Pre-wired square flat button mechanisms with a THEBEN module. Low voltage ≤ 48V

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass	RETAIL PRICE EX TAX
			471	472	474	477	478	479	
-668G-T		Mechanism 1 square flat button	076-668G471-T	076-668G472-T	076-668G474-T	076-668G477-T	076-668G478-T	076-668G479-T	102,00 €
-669G-T		Mechanism 2 square flat buttons	076-669G471-T	076-669G472-T	076-669G474-T	076-669G477-T	076-669G478-T	076-669G479-T	135,70 €
-670G-T		Mechanism 3 square flat buttons	076-670G471-T	076-670G472-T	076-670G474-T	076-670G477-T	076-670G478-T	076-670G479-T	189,30 €
-677G-T		Mechanism 3 square flat buttons L-shaped	076-677G471-T	076-677G472-T	076-677G474-T	076-677G477-T	076-677G478-T	076-677G479-T	189,30 €
-671G-T		Mechanism 4 square flat buttons	076-671G471-T	076-671G472-T	076-671G474-T	076-671G477-T	076-671G478-T	076-671G479-T	219,90 €

E.1

E.2

E.3

Pre-wired square flat button mechanisms with LED and a THEBEN module. Low voltage ≤ 48V

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass	RETAIL PRICE EX TAX
			471	472	474	477	478	479	
-668G-LT		Mechanism 1 square flat button with LED	076-668G471-LT	076-668G472-LT	076-668G474-LT	076-668G477-LT	076-668G478-LT	076-668G479-LT	113,30 €
-669G-LT		Mechanism 2 square flat buttons with LED	076-669G471-LT	076-669G472-LT	076-669G474-LT	076-669G477-LT	076-669G478-LT	076-669G479-LT	182,80 €
-670G-LT		Mechanism 3 square flat buttons with LED	076-670G471-LT	076-670G472-LT	076-670G474-LT	076-670G477-LT	076-670G478-LT	076-670G479-LT	275,20 €
-677G-LT		Mechanism 3 square flat buttons L-shaped with LED	076-677G471-LT	076-677G472-LT	076-677G474-LT	076-677G477-LT	076-677G478-LT	076-677G479-LT	275,20 €
-671G-LT		Mechanism 4 square flat buttons with LED	076-671G471-LT	076-671G472-LT	076-671G474-LT	076-671G477-LT	076-671G478-LT	076-671G479-LT	382,90 €

SINGLE COVER PLATES - PLAN - E0

A complete switch consists of a cover plate and single mechanisms for the functions required.

Single cover plates - Plan - E0

Single cover plate dimensions:
80x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
668-		Single cover plate 1 square flat button slot	668-471M-E0	668-472M-E0	668-474M-E0	668-477M-E0	668-478M-E0	668-479M-E0
669-		Single cover plate 2 square flat buttons slots	669-471M-E0	669-472M-E0	669-474M-E0	669-477M-E0	669-478M-E0	669-479M-E0
670-		Single cover plate 3 square flat buttons slots	670-471M-E0	670-472M-E0	670-474M-E0	670-477M-E0	670-478M-E0	670-479M-E0
677-		Single cover plate 3 square flat buttons slots L-shaped	677-471M-E0	677-472M-E0	677-474M-E0	677-477M-E0	677-478M-E0	677-479M-E0
671-		Single cover plate 4 square flat buttons slots	671-471M-E0	671-472M-E0	671-474M-E0	671-477M-E0	671-478M-E0	671-479M-E0
RETAIL PRICE EX TAX			83,00 €	83,00 €	85,70 €	85,70 €	83,80 €	83,80 €

SINGLE COVER PLATES - ANGLE - E2

A complete switch consists of a cover plate and single mechanisms for the functions required.

Single cover plates - Angle

Single cover plate dimensions:
80x80x5mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
668-		Single cover plate 1 square flat button slot	668-471M-E2	668-472M-E2	668-474M-E2	668-477M-E2	668-478M-E2	668-479M-E2
669-		Single cover plate 2 square flat buttons slots	669-471M-E2	669-472M-E2	669-474M-E2	669-477M-E2	669-478M-E2	669-479M-E2
670-		Single cover plate 3 square flat buttons slots	670-471M-E2	670-472M-E2	670-474M-E2	670-477M-E2	670-478M-E2	670-479M-E2
677-		Single cover plate 3 square flat buttons slots L-shaped	677-471M-E2	677-472M-E2	677-474M-E2	677-477M-E2	677-478M-E2	677-479M-E2
671-		Single cover plate 4 square flat buttons slots	671-471M-E2	671-472M-E2	671-474M-E2	671-477M-E2	671-478M-E2	671-479M-E2
RETAIL PRICE EX TAX			108,80 €	108,80 €	121,80 €	121,80 €	119,70 €	119,70 €

SINGLE COVER PLATES - VOLUME - E1

A complete switch consists of a cover plate and single mechanisms for the functions required.

Single cover plates - Volume

Single cover plate dimensions:
80x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
668-		Single cover plate 1 square flat button slot	668-471M-E1	668-472M-E1	668-474M-E1	668-477M-E1	668-478M-E1	668-479M-E1
669-		Single cover plate 2 square flat buttons slots	669-471M-E1	669-472M-E1	669-474M-E1	669-477M-E1	669-478M-E1	669-479M-E1
670-		Single cover plate 3 square flat buttons slots	670-471M-E1	670-472M-E1	670-474M-E1	670-477M-E1	670-478M-E1	670-479M-E1
677-		Single cover plate 3 square flat buttons slots L-shaped	677-471M-E1	677-472M-E1	677-474M-E1	677-477M-E1	677-478M-E1	677-479M-E1
671-		Single cover plate 4 square flat buttons slots	671-471M-E1	671-472M-E1	671-474M-E1	671-477M-E1	671-478M-E1	671-479M-E1
RETAIL PRICE EX TAX			108,80 €	108,80 €	121,80 €	121,80 €	119,70 €	119,70 €

SINGLE COVER PLATES - POINT - E4

A complete switch consists of a cover plate and single mechanisms for the functions required.

Single cover plates - Point

Single cover plate dimensions:
80x80x5mm

Single cover plates - Point			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
668-		Single cover plate 1 square flat button slot	668-471M-E4	668-472M-E4	668-474M-E4	668-477M-E4	668-478M-E4	668-479M-E4
669-		Single cover plate 2 square flat buttons slots	669-471M-E4	669-472M-E4	669-474M-E4	669-477M-E4	669-478M-E4	669-479M-E4
670-		Single cover plate 3 square flat buttons slots	670-471M-E4	670-472M-E4	670-474M-E4	670-477M-E4	670-478M-E4	670-479M-E4
677-		Single cover plate 3 square flat buttons slots L-shaped	677-471M-E4	677-472M-E4	677-474M-E4	677-477M-E4	677-478M-E4	677-479M-E4
671-		Single cover plate 4 square flat buttons slots	671-471M-E4	671-472M-E4	671-474M-E4	671-477M-E4	671-478M-E4	671-479M-E4
RETAIL PRICE EX TAX			108,80 €	108,80 €	121,80 €	121,80 €	119,70 €	119,70 €

SINGLE COVER PLATES - LIGNE - E5

A complete switch consists of a cover plate and single mechanisms for the functions required.


Single cover plates - Ligne

Single cover plate dimensions:
80x80x6mm

Single cover plates - Ligne

Single cover plate dimensions:
80x80x6mm

			Matt White	Matt Black	Gun Metal	Old Bronze	Satin Nickel	Satin Brass
			471	472	474	477	478	479
668-		Single cover plate 1 square flat button slot	668-471M-E5	668-472M-E5	668-474M-E5	668-477M-E5	668-478M-E5	668-479M-E5
669-		Single cover plate 2 square flat buttons slots	669-471M-E5	669-472M-E5	669-474M-E5	669-477M-E5	669-478M-E5	669-479M-E5
670-		Single cover plate 3 square flat buttons slots	670-471M-E5	670-472M-E5	670-474M-E5	670-477M-E5	670-478M-E5	670-479M-E5
677-		Single cover plate 3 square flat buttons slots L-shaped	677-471M-E5	677-472M-E5	677-474M-E5	677-477M-E5	677-478M-E5	677-479M-E5
671-		Single cover plate 4 square flat buttons slots	671-471M-E5	671-472M-E5	671-474M-E5	671-477M-E5	671-478M-E5	671-479M-E5
RETAIL PRICE EX TAX			115,00 €	115,00 €	127,50 €	127,50 €	125,50 €	125,50 €



E.1

E.2

E.3