

### **COVER PLATE DATA SHEET:**

Confidence Collection – Reading lamp







# 1 GENERAL INFORMATION

Material: Brass 5mm

Weight: 390g EL / 420g S / 530g D

Spacing between screws: 60mm

• Fixing: Screw-on only

Fitting: 3 minutes screw

- Compatible flush-mount boxes: LEG 080031 S LEG 080032 D
- Available tube length: 20cm / 30cm / 40cm

ARD 432002 EL





2700K – 170lm cower consumption 2W Lighting equivalent to 12W halogen
















1

### 2 FINISHES







# **COVER PLATE DATA SHEET:**


Confidence Collection – Reading lamp




Dimensions in mm







## 4 AVAILABLE FUNCTIONS







**GLOSSARY** 

**Lever:** toggle / push-button / changeover / roller shutter

### Leather sleevings for reading lamp



White leather CUIR1

Beige leather CUIR2

Red leather CUIR3

Brown leather CUIR4

Black leather CUIR5


Sept. 2021



### **COVER PLATE DATA SHEET:**

Confidence Collection – Reading lamp


## 5 WIRING



### 6 FITTING

- Wire the mechanism according to the corresponding diagram.
- 2. Simply engage the <u>cover plate + mecanism</u> <u>assembly</u> into the standard flush-mount box and screw in (4 Torx screws supplied).
- 3. Ensure vertical position is correct.

#### **SCREW COVER PLATE**



Note: For long or simple Narrow fronts with several rockers, example catalog 2034xx, the transformer cannot be placed in the flush-mounting box. It will have to be placed behind the bulkhead and it will be necessary to take care of it's good electrical insulation.

